EN CMC-TC Processing Unit II DK 7320.100

Assembly, Installation and Operation





FRIEDHELM LOH GROUP

Microsoft Windows is a registered trademark of Microsoft Corporation. Acrobat Reader is a registered trademark of Adobe Systems Incorporated.

Table of Contents

1	Documentation Notes5					
	1.1	Associated Documents5				
	1.2	CE Certification5				
	1.3	Retention of the Documents5				
	1.4	Used Symbols 5				
2	Safety Notes5					
3	Unit [Description				
	3.1	Housing6				
	3.2	Power Supply6				
	3.3	Network Properties				
	3.4	Connectable Sensors7				
	3.5	System Requirements7				
	3.6	Scope of Supply7				
	3.7	Accessories8				
	3.7.1	Required Accessories8				
	3.7.2	Optional Accessories9				
	3.8	Proper Use9				
4	Asse	mbly10				
	4.1	Assembly Notes 10				
	4.2	Assembling CMC-TC 10				
5	Insta	llation11				
	5.1	Safety and Other Notes11				
	5.2	Connecting the Power Supply				
	5.3	Establishing the Network Connection11				
	5.4	Establishing the Sensor Connection. 12				
	5.4.1	Connecting the Sensor 12				
	5.5	Connecting the Alarm Relay 12				
	5.6	Connecting the Voltage Extension Unit				
	5.7	Connecting the Programming Interface				
6	Comr	missioning 14				
7	Oper	ntion 16				
1		Monu Structure 16				
	7.1	Operating Notes 17				
	73	Setting the Base Configuration 17				
	731	Network Configuration 17				
	7.3.2	Configuring the Tran Receiver 17				
	733	Configuring the SNMPv1 Access 17				
	734	Configuring the Read/Write Community				
	1.0.4					
	7.3.5	Configuring the Authentication Traps 18				
	7.3.6	Changing the SNMP Version				
	7.3.7	Configuring the NTP 18				
	7.3.8	Configuring the PPP 19				
	7.3.9	Configuring the Sending of E-Mails 20				
CM	C-TC Proc	essing Unit II				

Documentation Notes 1

EN

7310	
7.0.10	Configuring the Syslog 20
7.3.11	Configuring the System Name, Contact and Location
7.3.12	Configuring the Passwords 20
7.3.13	Changing the HTTP Port 21
7.3.14	HTTPS (SSL) Function 21
7.3.15	Configuring the FTP Access
7.3.16	SFTP Access 21
7.3.17	Configuring the Timeout Window 21
7.3.18	Configuring the Telnet Access
7.3.19	Activating the Restart 22
7.3.20	Configuring the Connected Sensors. 22
7.3.21	General Configuration of the Processing Unit
7.3.22	Configuring the SMS Notification (GSM Unit)
7.3.23	Configuring the SMS Notification (ISDN Unit)
7.3.24	Entering the Telephone Numbers for SMS Notification
7.3.25	Calling the CMC Information Page 23
7.3.26	Resetting All Settings in the Main Menu 23
7.3.27	Manual Search for Sensors
7.4	Transferring Files Using the Serial Interface
7.5	Saving Files Using the Serial Interface
7.6	Access Using a Browser
7.6 7.6.1	Access Using a Browser
7.6 7.6.1 7.6.2	Access Using a Browser
7.6 7.6.1 7.6.2 7.6.3	
7.6 7.6.1 7.6.2 7.6.3 7.6.4	
7.6 7.6.1 7.6.2 7.6.3 7.6.4 7.6.5	24Access Using a Browser.24Login24Main Page View.24Main Settings25Configuring the Scheduler25Configuring the GMS Unit.26
7.6 7.6.1 7.6.2 7.6.3 7.6.4 7.6.5 7.6.6	
7.6 7.6.1 7.6.2 7.6.3 7.6.4 7.6.5 7.6.6 7.6.7	24Access Using a Browser.24Login24Main Page View.24Main Settings25Configuring the Scheduler25Configuring the GMS Unit.26Configuring the ISDN Unit26Configuring the Sending of E-Mails26
7.6 7.6.1 7.6.2 7.6.3 7.6.4 7.6.5 7.6.6 7.6.7 7.6.8	24Access Using a Browser.24Login24Main Page View.24Main Settings25Configuring the Scheduler25Configuring the GMS Unit.26Configuring the ISDN Unit26Configuring the Sending of E-Mails26Calling the Log File27
7.6 7.6.1 7.6.2 7.6.3 7.6.4 7.6.5 7.6.6 7.6.7 7.6.8 7.6.9	24Access Using a Browser.24Login24Main Page View.24Main Settings25Configuring the Scheduler25Configuring the GMS Unit.26Configuring the ISDN Unit26Configuring the Sending of E-Mails26Calling the Log File27Administration27
7.6 7.6.1 7.6.2 7.6.3 7.6.4 7.6.5 7.6.6 7.6.7 7.6.8 7.6.9 7.6.9 7.7	24Access Using a Browser.24Login24Main Page View.24Main Settings25Configuring the Scheduler25Configuring the GMS Unit.26Configuring the ISDN Unit26Configuring the Sending of E-Mails26Calling the Log File27Administration27Configuring the Sensors28
7.6 7.6.1 7.6.2 7.6.3 7.6.4 7.6.5 7.6.6 7.6.7 7.6.8 7.6.9 7.7 7.7.1	24Access Using a Browser.24Login24Main Page View.24Main Settings25Configuring the Scheduler25Configuring the GMS Unit.26Configuring the ISDN Unit26Configuring the Sending of E-Mails.26Calling the Log File27Administration27Configuring the Sensors28General Overview (Status Window).28
7.6 7.6.1 7.6.2 7.6.3 7.6.4 7.6.5 7.6.6 7.6.7 7.6.8 7.6.9 7.7 7.7.1 7.7.1 7.7.2	24Access Using a Browser.24Login24Main Page View.24Main Settings25Configuring the Scheduler25Configuring the GMS Unit.26Configuring the ISDN Unit26Configuring the Sending of E-Mails.26Calling the Log File27Administration27Configuring the Sensors28General Overview (Status Window).28Sensor Overview29
7.6 7.6.1 7.6.2 7.6.3 7.6.4 7.6.5 7.6.7 7.6.7 7.6.8 7.6.9 7.7 7.7.1 7.7.1 7.7.2 7.7.3	24Access Using a Browser.24Login24Main Page View.24Main Settings25Configuring the Scheduler25Configuring the GMS Unit.26Configuring the ISDN Unit26Configuring the Sending of E-Mails26Calling the Log File27Administration27Configuring the Sensors28General Overview (Status Window)28Sensor Overview (Sensor29General Overview (Sensor29
7.6 7.6.1 7.6.2 7.6.3 7.6.4 7.6.5 7.6.6 7.6.7 7.6.8 7.6.9 7.7 7.7.1 7.7.1 7.7.2 7.7.3 7.7.4	24Access Using a Browser.24Login24Main Page View.24Main Settings25Configuring the Scheduler25Configuring the GMS Unit.26Configuring the ISDN Unit26Configuring the Sending of E-Mails.26Calling the Log File27Administration27Configuring the Sensors28General Overview (Status Window).28Sensor Overview (Sensor29Configuring the Temperature Sensor 30
7.6 7.6.1 7.6.2 7.6.3 7.6.4 7.6.5 7.6.6 7.6.7 7.6.8 7.6.9 7.7 7.7.1 7.7.1 7.7.2 7.7.3 7.7.4 7.7.5	24Access Using a Browser.24Login24Main Page View.24Main Settings25Configuring the Scheduler25Configuring the GMS Unit.26Configuring the ISDN Unit26Configuring the Sending of E-Mails26Calling the Log File27Administration27Configuring the Sensors28General Overview (Status Window)28Sensor Overview29General Overview (Sensor29Configuring the Temperature Sensor 3030
7.6 7.6.1 7.6.2 7.6.3 7.6.4 7.6.5 7.6.6 7.6.7 7.6.8 7.6.9 7.7 7.7.1 7.7.2 7.7.1 7.7.2 7.7.3 7.7.4 7.7.5 7.7.6	24Access Using a Browser.24Login24Main Page View.24Main Settings25Configuring the Scheduler25Configuring the GMS Unit.26Configuring the ISDN Unit26Configuring the Sending of E-Mails26Calling the Log File27Administration27Configuring the Sensors28General Overview (Status Window)28Sensor Overview29General Overview (Sensor29Configuring the Temperature Sensor 3020Configuring the Analogue Sensor Input31
7.6 7.6.1 7.6.2 7.6.3 7.6.4 7.6.5 7.6.6 7.6.7 7.6.8 7.6.9 7.7 7.7.1 7.7.1 7.7.2 7.7.3 7.7.3 7.7.4 7.7.5 7.7.6 7.7.6	24Access Using a Browser.24Login24Main Page View.24Main Settings25Configuring the Scheduler25Configuring the GMS Unit.26Configuring the ISDN Unit26Configuring the Sending of E-Mails26Calling the Log File27Administration27Configuring the Sensors28General Overview (Status Window)28Sensor Overview29General Overview (Sensor20Configuring the Temperature Sensor 3020Configuring the Analogue Sensor Input31Configuring the Access Sensor32
7.6 7.6.1 7.6.2 7.6.3 7.6.4 7.6.5 7.6.6 7.6.7 7.6.8 7.6.9 7.7 7.7.1 7.7.2 7.7.3 7.7.4 7.7.5 7.7.6 7.7.6 7.7.7 7.7.7	24Access Using a Browser.24Login24Main Page View.24Main Settings25Configuring the Scheduler25Configuring the GMS Unit.26Configuring the ISDN Unit26Configuring the Sending of E-Mails26Calling the Log File27Administration27Configuring the Sensors28General Overview (Status Window)28Sensor Overview29General Overview (Sensor20Configuring the Temperature Sensor 3020Configuring the Analogue Sensor Input31Configuring the Access Sensor32Configuring the Vandalism Sensor32
7.6 7.6.1 7.6.2 7.6.3 7.6.4 7.6.5 7.6.6 7.6.7 7.6.8 7.6.9 7.7 7.7.1 7.7.1 7.7.2 7.7.3 7.7.4 7.7.5 7.7.6 7.7.7 7.7.6 7.7.7 7.7.8 7.7.9	24Access Using a Browser.24Login24Main Page View.24Main Settings25Configuring the Scheduler25Configuring the GMS Unit.26Configuring the ISDN Unit26Configuring the Sending of E-Mails26Calling the Log File27Administration27Configuring the Sensors28General Overview (Status Window)28Sensor Overview29General Overview (Sensor20Configuring the Temperature Sensor 3020Configuring the Analogue Sensor Input31Configuring the Access Sensor32Configuring the Vandalism Sensor33

1 Documentation Notes

7.7.11	Configuring the Motion Detector 34
7.7.12	Configuring the Digital Input Module.34
7.7.13	Configuring the Digital Output Relay Module
7.7.14	Configuring Switching Combinations for the Digital Relay Output Module36
7.7.15	Configuring the Voltage Monitor36
7.7.16	Configuring the Voltage Monitoring for the Voltage Monitor with IEC Switch Output
7.7.17	Configuring the Switch Output for the Voltage Monitor with IEC Switch Output 37
7.7.18	Configuring the Switching Combinations for the Voltage Monitor with IEC Switch Output
7.7.19	Configuring the Voltage Monitoring for the Voltage Monitor with 16 A Switch Output
7.7.20	Configuring the Switch Output for the Voltage Monitor with 16 A Switch Output
7.7.21	Configuring the Switching Combinations for the Voltage Monitor with 16 A Switch Output
7.7.22	Configuring the 48 V Voltage Monitor40
7.7.23	Configuring the Leakage Sensor40
7.7.24	Configuring the Acoustic Sensor41
7.7.25	Configuring the Fan Control System (FCS)42
7.7.26	Configuring the Fan Alarm System (FAS)43
7.7.27	Wireless Sensors44
7.8	Access Using Telnet44
7.8.1	Login Using Telnet44
7.8.2	Telnet Main Menu44
7.9	Performing a Software Update
7.10	Error Messages44
7.11	Structure of the MIB of the Processing Unit45
7.12	ActivePSM (4-way)47
7.12.1	Getting Acquainted with the Module Connections47
7.12.2	Display and Operating Elements47
7.12.3	Displays48
7.12.4	Setup Menu for the Local Pushbutton 48
7.12.5	Connecting the ActivePSM to the CMC- TC48
7.12.6	Monitoring Using a Browser49
7.12.7	Configuring the ActivePSM49
7.13	Metered PSM51
7.14	Monitoring the LCP and RTT I/O Unit51

	7.15	Access Control Using an External Access File51
	7.16	Saving and Transferring Configuration Files52
8	Mainte	enance and Cleaning
	8.1.1	Cleaning53
9	Storag	ge and Disposal53
	9.1.1	Storage 53
	9.1.2	Disposal 53
10	Chang 54	ges from software version 2.6
	10.1	Language selection for the browser interface
	10.2	Extended options under "Combinations"
	10.3	New functions for the alarm and event log54
	10.4	Test functions for traps, e-mail, SMS and pings
	10.5	Scaling of the 420 mA sensor inputs of the input module
	10.6	Server shutdown function 55
	10.7	Configuration of automatic door opening
	10.8	Delayed alarms 57
	10.9	Protection against cross-site scripting (XSS)
11	Custo	mer Service58
12	Techn	ical Specifications58
13	Techn	iical Glossary 59
14	Decla	ration of Conformity

1 Documentation Notes

The audience for this guide is the technical specialists familiar with the assembly, installation and operation of the CMC-TC Processing Unit.

• You should read this operating guide prior to the commissioning and store the guide so it is readily accessible for subsequent use.

Rittal cannot accept any liability for damage and operational malfunctions that result from the non-observance of this guide.

This guide applies to software level as of Version 2.50 of the Processing Unit II.

1.1 Associated Documents

The guides for other CMC-TC components and their safety notes also apply together with this guide.

This guide is also provided as a file on the accompanying CD-ROM:

German: 7320100VXXd.pdf

English: 7320100VXXe.pdf

To view the guide you require the Acrobat Reader program; Acrobat Reader can be downloaded from www.adobe.com

1.2 CE Certification

The conformance declaration is contained in the appendix.

1.3 Retention of the Documents

This guide and all associated documents are part of the product. They must be given to the operator of the unit and must be stored so they are available when needed.

1.4 Used Symbols

The following safety and other notes are used in this guide:

Symbol for a handling instruction:

 This bullet point indicates that you should perform an action.

Safety and other notes:



Danger! Immediate danger to health and life!

 $\underline{\mathbb{N}}$

Warning! Possible danger for the product and the environment!



Note! Useful information and special features.

2 Safety Notes

Observe the subsequent general safety notes for the installation and operation of the unit:

- Assembly and installation of the CMC-TC PU, in particular for wiring the enclosures with mains power, may be performed only by a trained electrician. Other tasks associated with the CMC-TC PU, such as the assembly and installation of system components with tested standard connectors, and the operation and configuration of the CMC-TC PU may be performed only by instructed personnel.
- Observe the valid regulations for the electrical installation for the country in which the unit is installed and operated, and the national regulations for accident prevention. Also observe any company-internal regulations (work, operating and safety regulations).
- Prior to working at the CMC-TC system, it must be disconnected from the power supply and protected against being switched on again.
- Use only genuine or recommended parts and accessories (see Section 3.7 Accessories). The use of other parts can void the liability for any resulting consequences.
- Do not make any changes to the CMC-TC Processing Unit that are not described in this guide or in the associated guides.
- The operational safety of the unit is guaranteed only for its approved use. The limit values stated in the technical specifications (see Chapter 12 Technical Specifications) may not be exceeded under any circumstances. In particular, this applies to the permitted ambient temperature range and to the permitted IP protection category. When used with a higher required IP protection category, the Rittal CMC-TC must be installed in a housing or enclosure with a higher IP protection category.
- The operation of the CMC-TC system in direct contact with water, aggressive materials or inflammable gases and vapours is prohibited.
- In addition to these general safety notes, also observe any special safety notes listed for the specific tasks in the individual sections.

3 Unit Description

3 Unit Description

The Computer Multi Control Top Concept Processing Unit II (subsequently called CMC-TC PU) is an "intelligent" enclosure monitoring system. It is installed in its own housing on the enclosure and uses the attached sensors in various forms to perform the complete physical monitoring of the enclosure, i.e. temperature, humidity, shock, smoke, voltage through to the complete cabinet locking and access control. All this information is transferred using SNMP to a management station where it can be administered.

The supplied CD-ROM contains software (CMC-TC Manager) that can be used to monitor and administer one or more CMC-TC PUs. The associated current version of the CMC-TC Manager is located on www.rimatrix5.com.

3.1 Housing

The CMC-TC Processing Unit is contained in its own housing that can be fastened with the supplied Velcro strips to the inner side of the side wall, to the punched sections with mounting flanges or to the shelves of the enclosure. Mounting units (see Section 3.7.1 Required Accessories) can also be used to install the housing.



Fig. 1 CMC-TC PU front side

Key

- 1 Acknowledge key (C key)
- 2 Status LED
- 3 Network LED
- 4 Serial interface (RS-232 connection)
- 5 Status LED for connected sensor units (Traffic LED)



Fig. 2 CMC-TC PU rear side

Key

- 1 Sensor units connections (1-4)
- 2 P-I²C connection
- 3 Alarm relay output (floating changeover contact)
- 4 Serial interface (IOIOI)
- 5 Network connection
- 6 Power supply connection (Power)

3.2 Power Supply

The CMC-TC Processing Unit is supplied with power using an external power pack. The connection cable for the external power pack is available as an accessory in various country variants. Choose the variant appropriate for the country-specific regulations. A selection of various connection cables is described in Section 3.7 Accessories.

All connected sensors are supplied with voltage from the CMC-TC Processing Unit. The CMC-TC Processing Unit has an integrated alarm relay equipped with a floating change-over contact. It is used for the optical or acoustic alarming. There is also a connection with a serial interface that can be used for various sensor units and expansion units.

3.3 Network Properties

The CMC-TC PU has an 10/100BaseT Ethernet network connection and supports the following protocols:

- RS232 serial interface: e.g. HyperTerminal
- in the Ethernet network: e.g. TELNET
- SNMPv1, compatible with popular management systems
- SNMPv3,
- HTTP, HTTPS
- FTP, SFTP
- NTP (Network Time Protocol)
- SSH (Secure Shell)
- SSL 3.0 (Secure Socket Layer)
- DHCP (Dynamic Host Configuration Protocol)

Optionally, the CMC-TC PU can also communicate using a Master Unit or using an ISDN or GSM unit. Associated information is contained on the Rittal homepage (www.rittal.de) or in Catalogue 32. Detailed documentation for the GSM and ISDN unit can also be found at www.rimatrix5.com.

Unit Description 3

The network connection is made using a suitable network cable with RJ-45 plug in the existing Ethernet network structure.

The communication is made using a standard browser and is operating-system-independent.

The number of Rittal CMC-TC Processing Units in the network is unlimited, provided adequate free IP addresses are available in the network. If this is not the case, up to ten CMC-TC PUs can be extended and administered using the Rittal CMC-TC Master. This distributed configuration allows you to also realise monitoring for enclosure suites without needing any large cabling effort.

The network protocols are used for communication (password query, switching commands, status queries, and alarm signals) between the Rittal CMC-TC PU, the administrators and the users in the network (network/ internet/ intranet).

The SNMP functionality is also independent of the operating system, only the network management protocol must support SNMP V1.0 or V3.0. In addition, the Rittal CMC-TC PU supports the standard MIB II. The private MIB is part of the scope of supply. Further information is provided on the supplied CD-ROM (CMC-TC PUII v1_1d.mib). The associated current version of the MIB can be found in the internet at www.rimatrix5.com.

The private MIB is required for integration in a building management software system. It decodes the transferred trap messages to produce unambiguous messages.

3.4

Connectable Sensors

Sensor	Model No.
Temperature sensor	DK 7320.500
Humidity sensor	DK 7320.510
Analogue sensor input module "4 – 20 mA"	DK 7320.520
Access sensor	DK 7320.530
Vandalism sensor	DK 7320.540
Airflow monitor	DK 7320.550
Smoke alarm	DK 7320.560
Motion sensor	DK 7320.570
Digital input module	DK 7320.580
Digital relay output module	DK 7320.590
Voltage monitor	DK 7320.600
Voltage monitor with switched output	DK 7320.610
Voltage monitor with 16 A switched output	DK 7320.611
48 V voltage monitor	DK 7320.620
Leakage sensor	DK 7320.630
Acoustic sensor	DK 7320.640

Tab. 1 Connectable sensors

The sensors are interlinked with the CMC-TC I/O unit using category RJ12 patch cables.

3.5 System Requirements

- Hardware: PC with serial interface and 10/100 Mbit network card
- Software: Operating system (Linux or Windows) Browser (IE 6.0 or equivalent)

3.6 Scope of Supply

The unit will be delivered in a packaging unit in fullyassembled state.

- Check the delivered components for completeness.
- Check that the packaging does not show any signs of damage.

3 Unit Description

Quantity	Designation
1	CMC-TC Processing Unit with net- work interface RJ-45 socket (10/100 BaseT)
2	Self-adhesive Velcro fasteners 90 x 15 mm
1	CD-ROM with software and operat- ing manual
1	Checklist for commissioning in German/English

Tab. 2 Scope of supply

3.7

EN

Accessories

3.7.1 Required Accessories

Depending on the country-specific specifications, you require an appropriate connection cable for the power pack of the CMC-TC PU.

Acces- sories	Designation	Pac ks of	Re- quired	Model No.
Power supply	Installation power pack 24 V IEC 100-230 V AC, UL approval, 3 A SELV	1	Yes, depend- ing on	7320.425
	Installation power pack 24 V IEC 48 V DC	1	supply	7320.435
Connec- tion cable for power pack	Connection cable IEC connector Country version D	1		7200.210
	Connection cable IEC connector Country version GB	1		7200.211
	Connection cable IEC connector Country version F/B	1	Yes, once for	7200.210
	Connection cable IEC connector Country version CH	1	power pack	7200.213
	Connection cable IEC connector Country version USA/CDN, UL approval FT1/VW1	1		7200.214
	Extension cable IEC connector and socket	1		7200.215
Assem- bly	1 U mounting unit	1		7320.440
	1 U single mounting unit with strain relief	1	Optional	7320.450
Program- ming cable	Programming cable D-Sub 9 to RJ 11	1	Yes, max. 1	7200.221
Exten- sion	Extension unit – voltage	1	Optional, max. 2	7200.520

Tab. 3 Required accessories

3.7.2 Optional Accessories

Accessories	Max. required number of items	Model No.
I/O Unit	4	DK 7320.210
Wireless I/O Unit	4	DK 7320.240
Access Unit	4	DK 7320.220
Climate Unit	4	DK 7320.230
Fan Control Sys- tem (FCS)	4	DK 7320.810
Fan Control Sys- tem (FCS)	4	DK 7858.488
Automatic Door opening control Unit	4	DK 7320.790
RTT I/O Unit	4	DK 3124.200
LCP	4	DK 3301.210
LCP	4	DK 3301.230
Active PSM 4-way	4x4	DK 7856.200
Active PSM 8-way	4x4	DK 7856.201
Active PSM 8-way (19")	4x4	DK 7200.001
Active PSM 6-way	4x4	DK 7856.203
Active PSM 6-way	4x4	DK 7856.204
PSM busbar with measurement	4	DK 7856.016
PSM measuring module	4	DK 7856.019
PCU	4x4	DK 7200.001
CMC-TC Display Unit II	1	DK 7320.491
CMC-TC GSM Unit	1	DK 7320.820
CMCTC ISDN Unit	1	DK 7320.830
Extension cable RJ12; 5.0 m	-	DK 7200.450
Extension cable RJ12; 1.0 m	-	DK 7320.814
Extension cable RJ45; 0.5 m		DK 7320.470
Extension cable RJ45; 2.0 m		DK 7320.472
Extension cable RJ45; 5.0 m		DK 7320.475
Extension cable RJ45; 10.0 m		DK 7320.481

3.8 Proper Use

The Rittal CMC-TC PUII serves as an enclosure monitoring system for the monitoring and administration of various enclosure parameters.

A use different from that described here is considered to be an improper use. Rittal cannot accept any liability for damage resulting from the improper use or the non-observance of this guide. The guides for the used accessories may apply.

Tab. 4 Optional accessories

4 Assembly

4 Assembly

EN

4.1 Assembly Notes

Install the CMC-TC PU in an enclosure or in a suitable housing system so that it also has additional protection from external effects. Also consider the permitted ambient temperature and humidity operational areas and the application-related required IP degree of protection (see Chapter 12, page 58).

4.2 Assembling CMC-TC



Fig. 3 Assembly with the mounting module

 Move the CMC-TC PU on the retaining plate of the mounting module. Ensure that the retaining plate sits between the guide rails of the CMC-TC PU.



Fig. 4 Assembly with Velcro fasteners

- Take the self-adhesive Velcro fasteners from the supplied accessories and remove the protective foil from the Velcro fasteners.
- Ensure that the adhesion surfaces are free from grease and dust.

• Attach the Velcro fasteners to the housing of the CMC-TC PU and position the CMC-TC PU at the required attachment location.



Fig. 5 Assembly with 1 U mounting unit

- 1. Remove the two upper screws of the trim piece.
- 2. Remove the trim piece.
- 3. Move the CMC-TC PU on the retaining plate of the mounting unit. Ensure that the retaining plate sits between the guide rails of the CMC-TC PU.
- 4. Replace the trim piece on the mounting unit.
- 5. Screw the trim piece back on the 1 U mounting unit.

5 Installation



Danger!

The assembly and installation may be performed only by trained specialists.

5.1 Safety and Other Notes

- The Rittal CMC-TC Processing Unit may be operated only with connected protective earth conductor. The protective earth conductor connection is made by plugging in the IEC connection cable. This requires that the IEC connection cable at the power supply side be connected with the protective earth conductor.
- The electrical connection voltage and frequency must conform to the rated values specified at the rear of the housing and in the technical specifications (see page 58).
- Before commencing work on the Rittal CMC-TC PU, it must be disconnected from the mains power supply and protected against being reconnected.
- Protect the connection cables using cable ties on the used housing or enclosure.
- To prevent unnecessary cable losses, the used cable lengths must not exceed the lengths specified in the technical specifications (see Chapter 12, page 58).

5.2 Connecting the Power Supply





Key

1 Power supply connection

You must connect the CMC-TC PU to the power supply using the power packs described in Section 3.7.1 Required Accessories.

The plug latches itself. After being connected to the power supply, the CMC-TC PU automatically begins a boot task that takes approximately three minutes. Once it has completed, the alarm LED illuminates green.

To remove the connection plug, pull back the moveable ring on the plug and then pull the complete plug out of the socket.



Fig. 7 Pin assignment (plug, from the front)

Key

- 1 Pin 1: Gnd
- 2 Pin 2: not assigned
- 3 Pin 3: +24 V

5.3 Establishing the Network Connection



Fig. 8 Establishing the network connection

Key

- 1 Network connection
- Use the RJ45 network cable to connect the CMC-TC PU with the existing Ethernet network structure.



Fig. 9 Checking the network connection

Key

1 Network LED

The network connection is established as soon as the Link LED lights green or orange. In addition, the Link LED starts to flash when data exchange occurs over the network:

Green: 10 Mbit transmission

Orange: 100 Mbit transmission

5.4

5 Installation

Establishing the Sensor Connection

5.4.1 Connecting the Sensor



Fig. 10 Establishing the sensor connection

Key

- 1 Sensor units connections (1-4)
- Insert the connection plug of the sensor units in any of the four connections.

The connected sensors will be detected automatically by the CMC-TC PU.



Fig. 11 Checking the sensor connection

Key

- 1 Acknowledge key (C key)
- 2 Status LED
- 3 Status LEDs for connected sensor units

When the sensors are connected and detected, a signal sounds and the Status LED of the connection flashes orange.

• Press the C key to confirm the connection of the sensor.

The acoustic signal is terminated and the Status LED changes from orange to green.

The CMC-TC Processing Unit continually polls the ports of the sensor units. Configuration changes to sensors are detected and reported automatically. The indication is made by the acoustic signal and by the Status LEDs.

5.5

Connecting the Alarm Relay

The alarm relay is connected using the floating changeover contact.

$\underline{\land}$

Warning! Damage danger!

Observe the technical specification of the alarm relay contained in the technical data. If these details are not observed, the alarm relay can be damaged.



Fig. 12 Connecting the alarm relay

Key

- 1 Alarm relay output (floating changeover contact)
- Connect the alarm relay with the RJ-12 sockets using RJ-12 connectors.

After the connection, you must configure the alarm relay using the software (see 7.3.21 General Configuration of the Processing Unit). The internal circuitry of the alarm relay is shown below:



Fig. 13 Power connection of the alarm relay

5.6 Connecting the Voltage Extension Unit

You can use the P-I²C connection (RJ-45 socket) to integrate a maximum of two voltage extension units (3-phase, DK 7200.520) in the CMC-TC PU. Further information is contained in the operating instructions of the voltage extension unit.



Fig. 14 $P-l^2C$ connection

Key

- 1 Voltage extension unit connection (P-I²C connection)
- Use an RJ45 cable to establish the connection between the voltage extension unit and the P-I²C connection of the Processing Unit.
- Set the DIP switch on the voltage extension unit as follows to address the voltage extension unit:

Switch setting	Addressing	
DIP switch at 1	First connected expansion unit	
DIP switch at 2	Second connected expansion unit	

Tab. 5 Addressing

5.7 Connecting the Programming Interface

If you want to configure the CMC-TC PU, for example, using a notebook, you can connect both devices with each other using the serial interface. The RS-232 interface of the CMC-TC PU is provided as RJ-10 front socket.



Fig. 15 RS-232 connection

Key

- 1 Serial interface (RS-232 connection as RJ-10 front socket)
- Connect the programming cable (DK 7200.221) with the RJ-10 front socket and with the serial interface of your PC.

6 Commissioning

6 Commissioning

ΕN

Once you have assembled the CMC-TC PU and installed all connections, you must now configure it. You can do this using either the serial interface (see Section 5.7 Connecting the Programming Interface), the network connection with an internet browser (see Section 7.6 Access Using a Browser) or Telnet (see Section 7.8 Access Using Telnet).

You must first establish the connection to the CMC-TC PU. This is shown in the following sections using the example of the "HyperTerminal" terminal program that is part of the Microsoft Windows 2000 operating system. The process is similar for other operating systems.

To start "HyperTerminal", click <Programs> - <Accessories> - <Communication> - <HyperTerminal>



Fig. 16 Enter name and select connection

- Enter name
- Assign symbol for connection

Verbinden mit ?X					
🧞 cmc					
Geben Sie die Rufnummer ein, die gewählt werden soll:					
Land/Region:	Deutschland (49)	~			
Ortskennzahl:	02772				
Rufnummer:					
Verbinden über:	COM1	-			
	OK Abbred	hen			

Fig. 17 Establish connection

- Select connection via COM Port
- Click "OK"

The properties of the selected COM ports must be specified once.

Ansc	hlußeinstellungen			
	Bjts pro Sekunde:	9600		•
	<u>D</u> atenbits:	8		
	<u>P</u> arität:	Keine		-
	Stopbits:	1		
	Pr <u>o</u> tokoll:	Kein		
			<u>S</u> tandard wiede	rherstellen
		к	Abbrechen	Überne

Fig. 18 COM port properties

• Enter the following parameters:

Transmission rate: 9600 bits per second

Data bits: 8

Parity: None

Stop bits: 1

Protocol: None

To ensure that the data is transferred without error, the standard level range must be observed for the RS-232 interface.

The login window for HyperTerminal appears.



Fig. 19 Login

You must enter your login name (CMC-TC login) and your password here. As supplied, "cmc" is set as default setting for both entries.

• Enter your login name (CMC-TC login) and your password.

You can change the password subsequently (see Section 7.3.12 Configuring the Passwords).

CMC-TC Processing Unit II



Fig. 20 HyperTerminal start window

If you have been able to establish the connection to the CMC-TC PU, the HyperTerminal configuration window with the CMC-TC PU configuration menu appears.

You can now set up the CMC-TC PU for your local conditions.

EN

7.1 Menu Structure

The terminal program menu has the following structure:

1 Network Configuration	
1.1 IP Configuration	1.4.2 IP Addr. CMC (DialIn)
1.1.1 IP Address	1.4.3 IP Addr. Client (Dialln)
1.1.2 IP Subnet Mask	1.4.4 Username (Dialln)
1.1.3 IP Def. Gateway	1.4.5 Password (Dialln)
1.1.4 Enable/Disable DHCP	1.4.6 Callback No. (Dialln)
1.1.5 Settings Ethernet Port	1.4.7 Enable PPP (Dialout)
1.2 SNMP Configuration	1.4.8 IP Addr. CMC (Dialout)
1.2.1 Trap Receiver Configura- tion	1.4.9 IP Addr. Client (Dialout)
1.2.1.1 IP Trap Receiver	1.4.A Username (Dialout)
1.2.1.2 Enable/Disable	1.4.B Password (Dialout)
1.2.1.3 IP Trap Receiver	1.4.C Phone Number (Dialout)
1.2.1.4 Enable/Disable	1.4.D Modem Type
1.2.1.5 IP Trap Receiver	1.4.E MSN (for ISDN)
1.2.1.6 Enable/Disable	1.4.F Modem Baud Rate
1.2.1.7 IP Trap Receiver	1.5 SMTP (email) Configuration
1.2.1.8 Enable/Disable	1.5.1 IP Addr. SMTP Server
1.2.2 SNMPv1 IP Access	1.5.2 SMTP Server Authentica- tion
1.2.2.1 SNMPv1 Manager	1.5.3 Username SMTP Server
1.2.2.2 SNMPv1 Manager	1.5.4 Password SMTP Server
1.2.2.3 SNMPv1 Manager	1.5.5 E-Mail Sender Name
1.2.2.4 SNMPv1 Manager	1.5.6 E-Mail Reply to
1.2.2.5 SNMPv1 Manager	1.5.7 E-Mail upon Unit Mes- sages
1.2.2.6 SNMPv1 Manager	1.5.8 E-Mail Address
1.2.2.7 SNMPv1 Manager	1.5.8.1 E-Mail Address
1.2.2.8 SNMPv1 Manager	1.5.8.2 E-Mail Address
1.2.2.9 SNMPv1 Manager	1.5.8.3 E-Mail Address
1.2.2.A SNMPv1 Manager	1.5.8.4 E-Mail Address
1.2.2.B SNMPv1 Manager	1.6 Syslog Configuration
1.2.2.C SNMPv1 Manager	1.6.1 IP Addr. Syslog Server
1.2.3 Read Community	1.6.2 IP Addr. Syslog Server
1.2.4 Write Community	1.6.3 Syslog Facility
1.2.5 Enable Auth. Traps	1.6.4 Enable Syslog
1.2.6 Change SNMP Version	1.7 System Name
1.2.7 Default SNMPv3 User Name	1.8 System Contact
1.2.8 Default SNMPv3 Pass- word	1.9 System Location
1.2.9 Confirm SNMPv3 us- mUser/Passw	

1.3 NTP Configuration	1.A Security
1.3.1 Enable NTP	1.A.1 Change Password User 'cmc'
1.3.2 IP Addr. NTP Server 1	1.A.2 Change Password User 'admin'
1.3.3 IP Addr. NTP Server 2	1.A.3 Change HTTP Port
1.3.4 NTP Offset to UTC	1.A.4 Enable SSL
1.3.5 NTP Update Frequency (h)	1.A.5 Change HTTPs Port
1.3.6 Dayl. Saving Time, Begin	1.B Enable FTP
1.3.7 Dayl. Saving Time, End	1.C Cons./Teln. Timeout Minu- tes
1.4 PPP Configuration	1.D Enable/Disable Telnet
1.4.1 Enable PPP (Dialln)	1.E Activate Actual Values
2 Sensor Units	
2.1 e.g. IO Unit 1:′CMC-TC- IOU′	2.1.1.C Trap Receiver 4/Log
2.1.1 e.g. Temperature Sensor	2.1.1.D Alarm Reset
2.1.1.1 Status	2.1.1.E Send SMS
2.1.1.2 Value	2.1.1.F Send E-Mail
2.1.1.3 Setpoint High	2.1.2 e.g. Humidity Sensor
2.1.1.4 Setpoint Warning	2.1.3 not available
2.1.1.5 Setpoint Low	2.1.4 not available
2.1.1.6 Message Text	2.1.5 Name Sensor Unit
2.1.1.7 Alarm Relay	2.1.4 Status of Unit
2.1.1.8 Beeper	2.2 Unit 2 not available
2.1.1.9 Trap Receiver 1	2.3 Unit 3 not available
2.1.1.A Trap Receiver 2	2.4 Unit 4 not available
2.1.1.B Trap Receiver 3	
3 General Configuration	
3.1 Temperature Unit	3.9.2 SMS Service Number
3.2 Beeper	3.9.3 ISDN MSN
3.3 Quit Alarm Relay	3.9.4 ISDN Pre-Dial Number
3.4 Alarm Relay Options	3.9.5 ISDN Command
3.5 Web Access	3.9.6 SMS upon Unit Message
3.6 Actual Date	3.9.7 SMS Phone Numbers
3.7 Actual Time	3.9.7.1 SMS Phone Number
3.8 Check Link	3.9.7.2 SMS Phone Number
3.9 SMS Configuration	3.9.7.3 SMS Phone Number
3.9.1 PIN GSM-Card	3.9.7.4 SMS Phone Number
4 Info Page	
5 Default, New Config. Of Senso	r Units, File Transfer
5.1 Set General Configuration to Default	5.3.1 Send File to CMC
5.2 Sensor Unit Detection	5.3.2 Receive File from CMC
5.3 Serial File Transfer (ZMo- dem)	

Fig. 21 Menu structure

7.2 Operating Notes

The following sections list as tables all the configuration parameters of the CMC-TC. The basic operation is always the same:

- Navigate within the menu structure using the "up" ↑ and "down" ↓ arrow keys.
- Scroll in fields with several predefined values using the "left" ← and "right" → arrow keys.
- Enter the required data in fields for text and numeric information from the keyboard.
- You can use the "Esc" key to cancel the inputs.
- Confirm all inputs with the "Return" or "Enter" key.

7.3 Setting the Base Configuration

The base configuration requires only the setting of the network configuration, the alarm relay and the trap receiver. You can make further settings using a browser or Telnet.

7.3.1 Network Configuration

You can use this menu to change your network settings.

Navigation	
Main menu – 1 Network Configuration – 1 IP Configuration	
Parameter	Explanation
IP Address	Enter your IP address (factory setting 192.168.0.190)
IP Subnet Mask	Enter your IP subnet mask address (factory setting 255.255.255.0)
IP Def. Gate- way	Enter the IP for the router (fac- tory setting 0.0.0.0)
Enable/Disable DHCP	Set whether the CMC-TC PU should obtain the IP address automatically: Enable or disable the function
Settings Ethernet Port	Configure the network interface of the CMC-TC PU on your network. Possible settings: Auto, 100/Half, 100/Full, 10/Half, 10/Full

Restart the system to save the settings:

Navigation

Main menu – 1 Network Configuration – D Activate Actual Values

Parameter	Explanation
Activate Actual Values	Activate new values: Select "Yes" and press the "Return" key to perform a restart.

If DHCP is enabled, then during the restart, a connection will be established to a DHCP server present in the network; an IP address is obtained from this server. If no IP address can be obtained from the DHCP server, the last valid IP address or default address will be used. A restart is also necessary when the DHCP is deactivated.

7.3.2 Configuring the Trap Receiver

To receive messages and information, so-called trap messages, from the CMC-TC PU, the IP address of the console on which a management software system (e.g. HP OpenView) is installed must be entered. The management software must support the SNMP protocol.

Navigation	
Main menu – 1 Network Configuration – 2 SNMP Configuration – 1 Trap Receiver Configuration	
Parameter	Explanation
IP Trap Re- ceiver	Enter the IP address of the receiver of the messages (factory setting 0.0.0.0).
Enable/Disable	Enable or disable the receiving at the preceding receiver.

Enter any additional recipients (maximum four) in the lines provided below.

7.3.3 Configuring the SNMPv1 Access

Management software that supports SNMP (e.g. HP OpenView or CMC-TC Manager) can access the CMC-TC PU via the network. To restrict the access, you can permit the access for required IP addresses (maximum 12). The access is then blocked for all other IP addresses that have not been entered. If no IP address has been entered, every management software system in the network has access to the CMC-TC PU.

Navigation

EN

Main menu – 1 Network Configuration – 2 SNMPv1 IP Access

Parameter	Explanation
SNMPv1 man- ager	Set the IP address for the PC with the SNMP management software that is to have access to the CMC-TC PU.

7.3.4 Configuring the Read/Write Community

To make the settings for a management software system on the CMC-TC, you must set the community of the Processing Unit and the management software.

Navigation	
Main menu – 1 Network Configuration – 2 SNMP Configuration – 3 Read Community / 4 Write Community	
Parameter	Explanation
3 Read Com- munity	Set the read community for the trap handling. Press the "Back-space" key to clear the factory setting and then enter the new name.
4 Write Com- munity	Set the write community for the trap handling. Press the "Back-space" key to clear the factory setting and then enter the new name.

7.3.5 Configuring the Authentication Traps

For an SNMP request (read or write) to the PUII with invalid Read/Write Community, the PUII sends an authentication trap to all activated trap receivers.

Navigation	
Main menu – 1 Network Configuration – 2 SNMP Configuration – 5 Enable Auth. Traps	
Parameter	Explanation
Enable Auth. Traps	Enable or disable FTP with the \leftarrow and \rightarrow arrow keys.

7.3.6 Changing the SNMP Version

As of software version 2.45, the Processing Unit II supports two types of SNMP. SNMPv1 and SNMPv3 are available. SNMPv3 provides a higher security functionality than SNMPv1. SNMPv3 requires an authentication.

Navigation

Main menu – 1 Network Configuration – 2 SNMP Configuration

Parameter	Explanation
6 Change SNMP Version	Set the SNMPv1 and SNMPv3 using the \leftarrow and \rightarrow arrow keys.
7 Default SNMPv3 User Name	Set the user name for SNMPv3 access 'cmc' (max. 20 charac- ters). Press the "Backspace" key to clear the factory setting and then enter the password.
8 Default SNMPv3 Password	Set the password for the SNMPv3 access 'cmc' (max. 20 characters). Press the "Backspace" key to clear the factory setting and then enter the password.
Confirm SNMPv3 us- mUser/Passw	Confirm the SNMPv3 authentication using the \leftarrow and \rightarrow arrow keys.

7.3.7 Configuring the NTP

The Network Time Protocol (NTP) is a standard for the time synchronisation of the internal clock using the network.

The NTP function synchronises the local internal clock of the CMC-TC using external time signals obtained from an NTP server. To use this function in the CMC-TC, the network connection to an NTP server must be possible. The IP addresses for two NTP servers can be entered (primary and secondary server). The time information from the NTP server is based on the coordinated world time (UTC) as reference time. The times in the various time zones of the world are derived from this time. Consequently, the current time zone must be set in the CMC-TC menu. The current date and the current time are then displayed with the correct value taking account of the time zone and the daylight saving status. Because the daylight saving begin and end in the various time zones differ, these two values can also be set in the CMC-TC.

Navigation	
Main menu – 1 Network Configuration – 3 NTP Configuration	
Parameter	Explanation
1 Enable NTP	Enable or disable NTP with the \leftarrow and \rightarrow arrow keys.
2 IP Addr. NTP Server 1	Set the first IP address of the NTP server. Press the "Back- space" key to clear the factory setting and then enter the IP address of the first NTP server.
3 IP Addr. NTP Server 2	Set the second IP address of the NTP server. Press the "Backspace" key to clear the factory setting and then enter the IP address of the second NTP server.
4 NTP Offset to UTC	Set the time zone of your country using the \leftarrow and \rightarrow arrow keys.
5 NTP Update Frequency (h)	Set the interval how often the Processing Unit should query the NTP server for the current date and time. The values must be set in hours.
	Press the "Backspace" key to clear the factory setting and then enter the interval time.
6 Dayl. Saving Time, Begin	Enter the begin of the daylight saving time. Press the "Backspace" key to clear the previous input and then enter the new data in the following format.
	m = month (112) n = week of the month (1 = first week, 5 = last week of the month) d = day (0 = Sunday, 6 = Saturday)
7 Dayl. Saving Time, End	Enter the end of the daylight saving time.
	Press the "Backspace" key to clear the previous input and then enter the new data in the following format.
	n = week of the month $(1 = first)$ week, 5 = last week of the month
	d = day (0 = Sunday, 6 = Saturday)

7.3.8 Configuring the PPP

You can administer the CMC-TC PU from a remote location using an analogue modem. To do this, connect the modem to the serial interface of the Processing Unit.

Navigation Main menu – 1 Network Configuration – 4 PPP Configuration **Parameter** Explanation 1 Enable PPP Enable or disable PPP with the (Dialln) \leftarrow and \rightarrow arrow keys. 2 IP Addr. Set the IP address of the Proc-CMC (Dialln) essing Unit to establish a connection from a client to the Processing Unit. 3 IP Addr. Set the IP address of the client Client (DialIn) to dial-in on the Processing Unit. 4 Username Set an arbitrary user name for (Dialln) the login on the Processing Unit (max. 20 characters). 5 Password Set an arbitrary password for the login on the Processing Unit (Dialln) (max. 20 characters). 6 Callback No. Enter the telephone number to (Dialln) which the Processing Unit should call back. 7 Enable PPP Enable or disable PPP with the (Dialout) \leftarrow and \rightarrow arrow keys. 8 IP Addr. Enter the IP address of the CMC (Dialout) Processing Unit for the dial-in on the client. Enter the IP address of the 9 IP Addr. Client (Dialout) client for the dial-in on the client. A Username Enter a user name as authenti-(Dialout) cation on the client. Note: The user name must be entered as user account in the client (max. 20 characters). **B** Password Enter a password as authenti-(Dialout) cation on the client. Note: The password must be identical with the password of the user account (max. 20 characters). C Phone Enter the telephone number Number that the Processing Unit should (Dialout) call in order to send a trap. D Modem Select the modem type: Ana-Туре logue, ISDN or GSM (when a

	GSM unit is used as modem, ensure that the SIM card does not have a PIN number).
E MSN (for ISDN)	When an ISDN modem is used, the MSN number must be en- tered.
F Modem Baud Rate	Bit rate with which the serial interface communicates with the external modem (for an analogue modem).

7.3.9 Configuring the Sending of E-Mails

As of software version 2.45, the CMC-TC PUII can send alarm messages as an e-mail via an SMTP server.

Navigation	
Main menu – 1 Network Configuration – 5 SMTP (E-mail) Configuration	
Parameter	Explanation
1 IP Addr. SMTP Server	Enter the IP address of the SMTP server.
2 SMTP Server Authentication	Enable (Yes) or disable (No) for an authentication on the SMTP server using the \leftarrow and \rightarrow ar- row keys.
3 Username SMTP Server	Enter the user name for the SMTP server.
4 Password SMTP Server	Enter the password for the SMTP server.
5 E-Mail Sen- der Name	Enter the sender address of the PUII.
6 E-Mail Reply to	If a user responds to this alarm message, the response mail will be sent to the entered address.
7 E-Mail upon Unit Messages	For a timeout, etc. on a unit, an e-mail can be sent as notification. Set "Yes" or "No" using the \leftarrow and \rightarrow arrow keys.
8 E-Mail Ad- dress	Enter up to four different e-mail addresses.

7.3.10 Configuring the Syslog

Navigation	
Main menu – 1 Network Configuration – 6 Syslog Configuration	
Parameter	Explanation

1 IP Addr. Syslog Server	Syslog Server 1 to which all alarm and event logs are sent.
2 IP Addr. Syslog Server	Syslog Server 2 to which all alarm and event logs are sent.
3 Syslog Facil- ity	Specifies the origin of the log message (Local0Local7). Used for differentiation when several systems are used.
4 Enable Sys- log	Switches the Syslog function on (enabled) or off (disabled). The default value is "disabled".

7.3.11 Configuring the System Name, Contact and Location

A unique name, a contact address (e-mail) and a location can be entered for the Processing Unit.

Navigation		
Main menu – 1 N	Main menu – 1 Network Configuration	
Parameter	Explanation	
6 System Na- me	The Processing Unit can be assigned any name. Press the "Backspace" key to clear the factory setting and then enter the new name.	
7 System Con- tact	Set the contact address (e.g. xyz@rittal.de). Press the "Backspace" key to clear the factory setting and then enter the new contact address.	
8 System Lo- cation	Enter the location name. Press the "Backspace" key to clear the factory setting and then enter the new installation loca- tion.	

7.3.12 Configuring the Passwords

You can change the passwords of the Processing Unit as required. The associated character length may not exceed 20 characters. Special characters are not permitted.

Navigation	
Main menu – 1 Network Configuration – 9 Secu- rity	
Parameter	Explanation
1 Change Password User ´cmc´	Set the password for the 'cmc' user (max. 20 characters). Press the "Backspace" key to clear the factory setting and then enter the password. To

	verify the new password, it must be re-entered a second time.
2 Change Password User 'admin'	Set the password for the 'admin' user (max. 20 charac- ters). Press the "Backspace" key to clear the factory setting and then enter the password. To verify the new password, it must be re-entered a second time.

7.3.13 Changing the HTTP Port

The standard http port for some networks is not assigned to port 80. You can change the port number to meet your requirements.

Navigation	
Main menu – 1 Network Configuration – 9 Secu- rity	
Parameter	Explanation
3 Change http Port	Set the http port 80-10000 (fac- tory setting: 80). Press the "Backspace" key to clear the factory setting and then enter the new port.

7.3.14 HTTPS (SSL) Function

For security, the Processing Unit supports SSL encryption. This encryption is used for the secure data exchange between the CMC-TC PU and the workstation.

Navigation	
Main menu – 1 Network Configuration – 9 Security	
Parameter	Explanation
4 Enable SSL	Enable or disable SSL with the \leftarrow and \rightarrow arrow keys.
5 Change https Port	Set the https port 80-10000 (factory setting: 443). Press the "Backspace" key to clear the factory setting and then enter the new port.

7.3.15 Configuring the FTP Access

The FTP access is used exclusively for uploading software updates, log files and configuration files. It can remain deactivated for normal usage.

Main menu – 1 Network Configuration – A Enable FTP	
Parameter	Explanation
A Enable FTP	Enable or disable FTP with the

 \leftarrow and \rightarrow arrow keys.

7.3.16 SFTP Access

The Secure FTP access includes the SSH data encryption. The function is always active and cannot be disabled. SFTP can be used as an alternative to FTP.

7.3.17 Configuring the Timeout Window

The console and Telnet Timeout window is used for the automatic logout after a defined time. If, for example, a user has not performed any action on the Processing Unit over a period of five minutes, the user will be logged off automatically.

Navigation	
Main menu – 1 Network Configuration – B Cons./Teln. Timeout Minutes	
Parameter	Explanation
B Cons./Teln. Timeout Min- utes	Set the timeout function in min- utes. 0 = No timeout 5 = If no changes have been made during the previous five minutes. Press the "Backspace" key to clear the factory setting and then enter the new time.

7.3.18 Configuring the Telnet Access

Telnet provides the same administrative rights as those using the serial interface. If Telnet access is not wanted, you can deactivate it.

NavigationMain menu – 1 Network Configuration – C Enable/Disable TelnetParameterExplanationC Enable /
Disable TelnetEnable or disable Telnet with
the \leftarrow and \rightarrow arrow keys.



> Note!

In addition to access using Telnet, an SSH client (e.g. Putty) can be used to make an encrypted access to the PUII

configuration.	Unlike the Telnet access,
the SSH acces	ss cannot be disabled.
7.3.19 Activating th	e Restart

You can also restart (reboot) the Processing Unit after a software crash using this menu item.

Navigation

Main menu – 1 Network Configuration – D Activate Actual Values

Parameter	Explanation
D Activate Actual Values	Perform restart (Yes) or do not perform restart (No) using the \leftarrow and \rightarrow arrow keys.

7.3.20 Configuring the Connected Sensors

The sensors can be configured using Hyper-Terminal. This method of operation is required only when the browser setting is set to view mode.

Navigation	
Main menu – 2 Sensor Units	
Parameter	Explanation
1-4 Connected Units	Access to the connected units with the installed sensors.

7.3.21 General Configuration of the Processing Unit

The main configuration of the Processing Unit is used to setup the hardware and the units of the sensors. You can also set up the date and time, temperature unit, alarm relay, etc.

Navigation	
Main menu – 3 General Configuration	
Parameter	Explanation
1 Temperature Unit	Set the Celsius or Fahrenheit unit using the \leftarrow and \rightarrow arrow keys.
2 Beeper	Set on (alarm beeper on) or off (alarm beeper off) using the \leftarrow and \rightarrow arrow keys.
3 Quit Alarm Relay	Set the alarm relay acknowl- edge using the \leftarrow and \rightarrow arrow keys. In case of an alarm, the "C key" can be used to reset the alarm relay on the PU.

	Disabled = the alarm relay is reset automatically after an alarm. Enabled = the alarm relay is reset after an alarm by pressing the "C key".
4 Alarm Relay Options	Set the alarm relay function using the \leftarrow and \rightarrow arrow keys. Close = alarm relay contact is closed. Open = alarm relay contact is open. Off = alarm relay contact is disabled.
5 Web Access	Set the web access using the \leftarrow and \rightarrow arrow keys. Full = full access. All current values can be fetched and set- tings changed on the Process- ing Unit. View = display. Only the current values are displayed. The set- tings cannot be changed. No = block web access. The Processing Unit can no longer be called from the web.
6 Actual Date	Set the current date. Press the "Backspace" key to clear the factory setting and then enter the current date. Date format: dd.mm.yyyy
7 Actual Time	Set the current time. Press the "Backspace" key to clear the factory setting and then enter the current time. Time format: hh:mm:ss
8 Check Link	The individual Trap Receivers can be checked for reachability. Press the "Backspace" key to clear the factory setting and enter the number of the Trap Receiver.
9 SMS Con- figuration	Applies only when an ISDN or GSM unit is connected.

7.3.22 Configuring the SMS Notification (GSM Unit)

This function is only active if an ISDN unit is connected.

Navigation		
Main menu – 3 General Configuration – 9 SMS Configuration		
Parameter	Explanation	

1 PIN GSM Card	Set the 4-digit PIN number of the GSM card.
2 SMS Service Number	Set the SMS service number. The specified format must be observed, e.g. +491710760000
6 SMS upon Unit Messages	For a timeout, etc., an SMS for notification can be sent to a unit. Set using the \leftarrow and \rightarrow arrow keys, "Yes" or "No".

7.3.23 Configuring the SMS Notification (ISDN Unit)

This function is only active if an ISDN unit is connected.

Navigation	
Main menu – 3 General Configuration – 9 SMS Configuration	
Parameter	Explanation
3 ISDN MSN	Set the MSN number of your ISDN connection. The number must be entered as follows: +49/2772/123456
4 ISDN Pre- Dial Number	Set the number to obtain an external line. This entry is required when you have connected the ISDN unit to a telephone system.
5 ISDN Com- mand	Set the SMS command for sending SMS messages over the fixed-line network. For example, "8888 ANMELD" for the T-Com network. or "09003266900" for the Arcor network.
6 SMS upon Unit Messages	For a timeout, etc., an SMS for notification can be sent to a unit. Set using the \leftarrow and \rightarrow arrow keys, "Yes" or "No".

7.3.24 Entering the Telephone Numbers for SMS Notification

This function is only active if an ISDN or GSM unit is connected.

Navigation

Main menu – 3 General Configuration – 9 SMS Configuration – 7 SMS Phone Numbers

Parameter	Explanation
1 - 4 SMS	Set the SMS target call number.
Phone Number	E.g. +4927725051234

7.3.25 Calling the CMC Information Page

To display the current information for the Processing Unit, you can display an information page from the Processing Unit. This page displays all settings for the network connection, software and hardware version, etc.

Navigation	
Main menu – 4 Info Page	
Parameter	Explanation
4 Info Page	The CMC Info Page provides a complete overview of the Processing Unit configuration.

7.3.26 Resetting All Settings in the Main Menu

You can reset all your sensor settings. Passwords and network settings are not reset.

Navigation		
Main menu – 5 Default, NewConfig. of Sensor Units, File Transfer		
Parameter	Explanation	
1 Set General Configuration to Default	Activate (Yes) or deactivate (No) the sensor settings using the \leftarrow and \rightarrow arrow keys.	

7.3.27 Manual Search for Sensors

Under some circumstances, the sensors for the Processing Unit are not detected immediately. In this case, you can activate the manual search for the sensors.

Navigation

Main menu – 5 Default, NewConfig. of Sensor Units, File Transfer

Parameter	Explanation
2 Sensor Unit Detection	Activate (Yes) or deactivate (No) the sensor detection using the \leftarrow and \rightarrow arrow keys.

EN

7.4 Transferring Files Using the Serial 7 Interface

You can transfer individual files, such as access files, to the Processing Unit using the serial interface.

Navigation	
Main menu – 5 Default, NewConfig. of Sensor Units, File Transfer – 3 Serial File Transfer (ZModem)	
Parameter	Explanation
1 Send File to CMC	Start (Yes) or do not start (No) the Zmodem using the \leftarrow and \rightarrow arrow keys.

You will now be requested to specify the path for the file to be transferred. To do this, click "Find" and search for the file.

Select Zmodem as protocol and click "Send". Once the file has been transferred, press the Esc key to return to the main menu and to save the setting.

7.5 Saving Files Using the Serial Interface

You can save individual files from the Processing Unit on your PC.

Nav	viaa	tior
114	rige	

Main menu – 5 Default, New Config. of Sensor Units, File Transfer – 3 Serial File Transfer (ZModem)

Parameter	Explanation
2 Receive File from CMC	Enter the name of the file that you want to save from the Processing Unit on your com- puter.

Now use the find icon to select a target folder for the file to be saved.

Enter Zmodem as receive protocol and click "Receive" to confirm your input.

7.6 Access Using a Browser

Open your Web browser as usual. Enter the IP address of the Processing Unit in the address field and call the page.

7.6.1 Login



Fig. 22 Login window

Key	
,	

- 1 User name
- 2 Password
- 3 Login or Clear button

Enter in the login window the http user name and the http password of the Processing Unit.

Factory setting:	
User name:	admin
Password:	admin

To confirm the input, click the Login button. To clear the input, click the Clear button.

7.6.2 Main Page View



Fig. 23 Main page overview

Key

- 1 Status window
- As shown above
- 2 IP address of the Processing Unit
- 3 Link to the main page view
- 4 Setup Link
- 5 Alarm and event logging link
- 6 Administration link
- 7 User name
- 8 User logout

The following buttons can be used to navigate easier between the individual pages:



Q

Setup button: Links from the overview page (main or units overview) to the setup pages of the associated unit.

Overview button: Links from the main overview page to the units overview page.



Back button: This can be used to go back one page from any page.

Home button: Links from each units overview page or from the setup pages directly to the home page.

7.6.3

Main Settings



Fig. 24 Main settings

Key 1

- General This link can be used to make basic settings of the PUII (name, location, contact name, temperature unit, beeper, alarm relay acknowledge, alarm relay options, background colour, date and time).
- 2 Timer function (see 7.6.4 Configuring the Scheduler)
- 3 SMS unit (see 7.6.5 Configuring the GSM Unit or 7.6.6 Configuring the ISDN Unit)
- 4 E-Mail (SMTP)
- 5 Event Logging (see 7.6.8 Calling the Log File)
- 6 Administration links to the user administration, if you are logged on as administrator. Otherwise you can only change your own password.
- 7 Date and time of the last alarm/warning status change
- 8 Current status of the alarms and warnings
- 9 Logged-in user

7.6.4 Configuring the Scheduler

You can program up to eight timers.

- Specify whether the timer is to be active or inactive.
- 2. Select the day or days when the timer is to be active.
- 3. Now specify the time window (format: hh:mm).
- 4. Specify what the timer should perform during this time.

The following functions can be selected from item 4:

Designation	Function
dis.keypad unit	Deactivates the associ- ated keypad.
unlock unit	Opens the door (front or rear) of the associated unit.
disable Trap Receiver	No alarms are sent to the trap receiver.
disable SMS (general)	Deactivates the SMS

ΕN

	notification function.
Alarm Scheduler	Disables the alarms con- figured for "Scheduled Alarm off" in the sensor configuration.
disable Trap Receiver	Deactivates the SMS notification function for a specific receiver.
disable E-Mail Rec.	Deactivates the e-mail notification function for a specific receiver.
Status E-Mail to Rec.	Sends a status e-mail to a receiver. A maximum of 150 mes- sages can be transferred for each status mail. If more than 150 mes- sages are present, only the most recent 150 will be sent in the e-mail.

7.6.5 Configuring the GMS Unit

1	Se	tup SMS-Unit
3	PIN GSM-Card Service Center GSM ISDN MSN ISDN Pre Dial ISDN Command Unit Messages Phone Number 1 Phone Number 2 Phone Number 3 Phone Number 4	
	SMS-Info	no SMS unit found
	/	Accept Reset
	5	

Fig. 25 Setup for SMS unit

Key

1 PIN GSM-Card

Enter here the PIN for your GSM card.

- 2 Service Centre GSM Set the Service Centre number. This number varies depending on the mobile telephone provider. Observe the notation (e.g. +491710760000).
- 3 Unit Messages Set whether for a unit error, for example, timeout or configuration change, an SMS should be sent.
- 4 Enter the target call numbers (max. four target call numbers, e.g. +4927725051234).
- 5 Accept or Reset button Accept or reset the settings.

7.6.6 Configuring the ISDN Unit





Key

3

1 ISDN MSN Enter here the MSN number of the ISDN connection. The MSN number must be entered as follows: +49/2772/123456

2 ISDN Pre Dial

If the ISDN unit is to be connected to a telephone system, you must enter the number used to obtain an external line, for example, "0".

- ISDN Command Specify the SMS command so that SMS can be sent over the fixed-line network (e.g. the following command must be entered for T-Com: "8888 AN-MELD").
- 4 Unit Messages Set whether for a unit error, for example, timeout or configuration change, an SMS should be sent.
- 5 Phone Number 1 4 Enter here the target call numbers to receive an SMS when an alarm is issued; these numbers are entered in the following format: +492772123456.
- 6 Accept or Reset button Accept or reset the settings.

7.6.7 Configuring the Sending of E-Mails

If you have not entered the e-mail addresses of the alarm recipient using Hyperterminal, you can do this here now. Proceed as follows:



Fig. 27 Setup for sending e-mails

Key

IP SMTP Server Enter here the IP address of the SMTP server. CMC-TC Processing Unit II

- SMTP Authent.
 If your SMTP server requires a user name and password for the authentication, click "Yes".
- 3 Username Server Enter the user name for the authentication.
- 4 Password Server Enter the password of the server for the authentication and repeat the input in the "Retype" field.
- 5 Sender Name Enter a sender name. This name is then used as sender in the alarm mail.
 - Reply to If a reply is to be sent for the alarm mail, you can specify the e-mail address for the recipient to which the response mail is to be forwarded.
- 7 Unit Messages If the individual units display an error message (configuration change, timeout), you can send this alarm as an e-mail. To do this, click "Yes".
- 8 E-Mail Address 1-4 Enter here up to four different e-mail addresses.

To accept and save the settings, click the "Accept" button.

7.6.8 Calling the Log File

6

Two different types of logging are performed. Firstly, the "Alarm Log". This displays all alarms that the logged-in user is permitted to view.

1	Alarm Log
	30.06.2007 / 18:17:18 Temp VO [01 02]. Access Sensor: OK
	30.06.2007 / 18:17:14 Temp I/O [01 02], Access Sensor: Alarm
	30.06.2007 / 18:17:13 Temp VO [D1 02], Access Sensor: OK
	30.06.2007 / 18:17:12 Temp VO [01/02], Access Sensor: Alarm
	30.06.2007 / 18:15:51 Temp VO [01]02], Access Sensor: OK
	30.05.2007 / 18:15:45 Temp VO [01 02], Access Sensor: Alarm
	30.06.2007 / 18:15:34 Temp I/O [01]02]. Access Sensor: OK
	30.06.2007 / 18:15:25 Temp VO [D1]02], Access Sensor: Alarm
	30.06.2007 / 13:25:17 Temp I/O [01]02], Access Sensor: OK
	30.06.2007 / 13:25:15 Temp VO [D1]02], Access Sensor: Alarm
	30.06.2007 / 13:24:55 Temp VO [01 02]. Access Sensor: OK
	29.06.2007 / 17:57:07 Temp I/O [01]02], Access Sensor: Alarm
	29.06.2007 / 08:37:04 Temp VO [01 02], Access Sensor: OK
	29.06.2007 / 08:37:01 Temp I/O [D1]02], Access Sensor: Alarm
	29.06.2007 / 08:36:43 Temp I/O [01/02], Access Sensor: OK
	29.06.2007 / 08:36:35 Temp I/O [01 02], Access Sensor: Alarm
	29.06.2007 / 08:36:28 Temp VO [01]02], Access Sensor: OK
	29.06.2007 / 08:36:20 Temp I/O (01)021 Access Sensor: Alarm
	21.06.2007 / 16:32:38 Temp 90 [01]01], Temperature Sensor : OK (28°C)
	21.05.2007 / 15:32-25 Temp VO [01]01], Temperature Sensor : Too High (2810
	21.06.2007 / 16:30:45 Temp I/0 [01]01], Temperature Sensor : OK (28°C)
	21.05.2007 / 15:30:23 Temp VO (01)01), Temperature Sensor : Too High (291)

Fig. 28 Alarm log

Secondly, the "Event Log". This shows the time when each user performed a login and logoff, when an update was performed, when a file was uploaded or downloaded, and various other events.

Event Log
06.07.2007 / 17:06:31 'admin' (IP 130.0.169.159) logged in
02.07.2007 / 14:40:32 'admin' (IP 130.0.169.159) logged out
02.07.2007 / 14:38:18 'admin' (IP 130.0.169.159) logged in
30.06.2007 / 13:58:12 'admin' (IP 130.0.169.159) logged out
30.06.2007 / 13:58:12 'admin' session (IP 130.0.109.159) terminated (Timeout)
30.06.2007 / 13:24:39 'admin' (IP 130.0.169.159) logged in
29.06.2007 / 08:41:50 'admin' (IP 130.0.169.159) logged out
29.06.2007 / 08:36:11 'admin' (IP 130.0.169.159) logged in
24.06.2007 / 16:45:57 User 'cmc' session (IP 130.0.156.242) terminated (Timeout)
24.06.2007 / 16:15:55 User 'cmc' (IP 130.0.156.242) logged in
24.06.2007 / 11:42:34 User 'cmc' session (IP 130.0.156.242) terminated (Timeout)
24.06.2007 / 11:12:19 User 'cmc' (IP 130.0.156.242) logged in
23.06.2007 / 13:19:10 User Configuration File 'upload/cmc.user' from 21.06.2007
15:03:36 successfully restored
23.06.2007 / 13:08:59 'admin' (IP 130.0.169.159) logged out
23.06.2007 / 13:06:33 Active 'admin' (IP 130.0.169.159) session terminated, new
'admin' (IP 130.0.169.159) logged in
23.06.2007 / 13:06:16 Active 'admin' (IP 130.0.169.159) session terminated, new
admin' (P 130.0.169.169) logged in
23.06.2007 / 13:06:02 User Configuration File uploadicmc.user from 21.06.2007
22 06 2007 / 12:05:52 (a deplet //D 12:0 0 10:0 10:0 langed in
23.06.2007 / 13:05:37 'admin' //P 130.0 169 169 logged out
and a set of the set o

Fig. 29 Event log

Up to 100 messages are recorded. If the storage area is full with 100 messages and a new message is received, the oldest message will be deleted.

7.6.9 Administration

Login as administrator on the login page (see 7.6.1 Login).



Fig. 30 User administration

Key

- 1 Page title
- 2 User page:
 - Up to sixteen different users or user groups can be created (max. 20 characters; special characters are not permitted).
- 3 Username: Enter the user name or group name. Maximum character length: 20 characters (special characters are not permitted).
- 4 Password:

The password may contain a maximum of 20 characters (special characters are not permitted).

5 Unit 1 – 6:

The access rights for the individual units are specified per user or user group.

No Access: The user does not have any access to the unit.

Read: User only has read rights. Settings cannot be changed.

Read/Write: User has read and write rights. User has access to the unit; the user can read and change the settings but not switch the unit 1 - 4. Read/Write/Switch: User has read, write and switching rights. Connected socket strips, and digital and analogue inputs/outputs can be operated by the user.

6 General Setup:

No Access: The user does not have any access to the unit.

Read: User only has read rights. Settings cannot be changed.

Read/Write: User has read and write rights. The user has access to the unit, and can read and change the settings.

7 Timer Functions:

No Access: The user does not have any access to the unit.

Read: User only has read rights. Settings cannot be changed.

Read/Write: User has read and write rights. The user has access to the unit, and can read and change the settings.

8 SMS Setup:

No Access: The user does not have any access to the unit.

EN

	Read: User only has read rights. Settings cannot be changed. Read/Write: User has read and write rights. The user has access to the unit, and can read and change the settings.	Key 1 2	Connection number and type of the sensor units. Name of the sensor unit: Click to change to the sensor overview (7.7.2) of the I/O unit.
9	Alarm Logs: No Access: The user does not have any access to the Event Logging page. Own alarms: If a user only has access to one or more units, the user will see only the alarm mes- sages of the units assigned to the user. All alarms: The logged in user is permitted to view all alarm messages.	5	green: No warning/alarm yellow: Warning red: Alarm (malfunction) unit detected: New sensor unit has been connected to the PUII Configuration changed: New sensor connected to the I/O unit or configuration change of a sensor
10	Timeout: If a user does not make any activity in the browser window for an extended period of time, the user will be logged off from the system after a set time.	4	Acknowledge events Click the Clear button to acknowledge timeouts and configuration changes. This causes the CMC-TC PU to be queried again and the web page rebuilt.
11	Login Status: If you are logged in as administrator, you can log off logged in users.	5	Refresh Forces an immediate updating of the CMC-TC PU web page. The sensor overview will also be updated automati-
12	Accept/Reset Button: Accept button: Accept settings. Reset button: Settings are not accepted.		cally every ten seconds.
	> Note!	7.7.	2

If you are logged in as user, you can only change your password in the Administration window.

Logged in users can only change their own password.

7.7 Configuring the Sensors

You can make various settings for each sensor. The CMC-TC PU has four connections to each of which a sensor unit (I/O Unit, Access Unit, etc.) can be connected.

Navigation	
Main menu	

The sensor overview window appears.

7.7.1 General Overview (Status Window)

	1 2 3					
			Over	view		
Unit	Type	Name			Status	
1	RLCP Unit	Kuehlung			No Alarm	۹ 📅
2	Wireless Unit	CMC-TC-IO	W		Alarm	۹ 📊
3	Climate Unit	CU-Server			No Alarm	۹ 📊
4	RTT Unit	TopTherm			No Alarm	٩ 📊
	Clear Refresh					
		4	Ę	5		



Fig. 32 Sensors on an I/O unit overview

Key

5

- 1 Connection number and sensor type.
- 2 Message text of the sensor. Can be selected freely using the sensor configuration (7.7.3).
- 3 Status or measurement value of the sensor. The font colour indicates the status of the sensor. For analogue values, an arrow indicates the overshooting or undershooting of the alarm or warning thresholds.
- 4 Acknowledge events Click the Clear button to acknowledge timeouts and configuration changes. This causes the CMC-TC PU to be queried again and the web page rebuilt.
 - Refresh Forces an immediate updating of the CMC-TC PU web page.

The sensor overview is also updated automatically every ten seconds.

Warning and alarm status of the sensors (overall) green: No warning/alarm yellow: Warning red: alarm (malfunction)

7.7.3 General Overview (Sensor Configuration)

You can individually set the attached sensors. Because the structure of the configuration overview is generally always identical, it is shown here as an example.

To reach this page, click the message text of the sensor or the tool icon **1** on the general overview (status window) of the PUII.



Fig. 33 Configuring the sensor – overview

Key

- 1 Connected sensor type.
- 2 Current status of the connected sensor.
- 3 This message text will also be transferred when a warning/alarm message is sent and serves as information for the recipient of the message to identify the sensor. You can delete the specified text and add your own message text (e.g. TempSensor-Rack1).
- 7 You can set for each sensor whether (enable) or not (disable) the alarm relay is to be switched for an alarm.
- 8 You can set for each sensor whether (enable) or not (disable) the integrated alarm beeper is to be activated for an alarm.
- 9 You can set for each sensor type whether after a warning or alarm status the CMC-TC PU should self-acknowledge (auto) or the administrator must acknowledge manually (manual).
- 10 By clicking the individual option fields you can determine to which of the entered trap receivers the traps for this sensor are to be sent.
- 11 By clicking the individual option fields you can set which alarm configuration is to be enabled or disabled. You can specify the individual functions in the "Setup – Timer" menu item and assign the associated scheduler.
- 12 You can enter up to four mobile wireless numbers that you entered previously at Setup – SMS Unit; each number is separated with the ampersand character "&" (e.g. 1&2&3&4).
- 13 You can enter up to four e-mail addresses that you entered previously at Setup E-Mail (SMTP); each number is separated with the ampersand character "&" (e.g. 1&2&3&4).
- 14 Accept all changes.
- 15 Reset all settings to their default values.

The following buttons can be used to navigate easier between the individual pages:



Back button: This can be used to go back one page from any page.

Home button: Links from each units overview page or from the setup pages directly to the home page.

7.7.4 Configuring the Temperature Sensor

You configure the temperature sensor (DK 7320.500) as follows:

Navigation

Main menu – Setup – Click the sensor name				
Parameter	Explanation			
1 n	Connection number of the sen- sor.			
Туре	Sensor type. Will be detected automatically.			
Sensor Status	Measured temperature and sensor status. Green = OK, yellow = warning, red = alarm.			
Message Text	The message text which is also transferred when a warn- ing/alarm message is sent. Enter here a designation that uniquely identifies your sensor, e.g. "TempSensor rack 1".			
Setpoint High	Temperature limit which when overshot causes an alarm message to be issued.			
Setpoint Warn- ing	Temperature limit which when overshot causes a warning message to be issued.			
Setpoint Low	Temperature limit which when undershot causes an alarm message to be issued.			
Alarm Relay	Whether (enable) or not (dis- able) an alarm relay should switch in the event of a warn- ing/alarm.			
Alarm Beeper	Whether (enable) or not (dis- able) an audio signal should be issued in the event of a warn- ing/alarm.			
Alarm Reset	Should a warning/alarm be acknowledged automatically (Auto) or does it need to be acknowledged by the adminis- trator (Manual).			
Trap Receiver	Specify which of the entered trap receivers is to be sent warning/alarm messages. Enter the trap receivers at 7.3.2 Configuring the Trap Receiver.			
Scheduled Alarm Off	Specify which alarm configura- tion should be enabled or dis- abled. The individual functions can be setup from the "Setup – Timer" menu item.			

Send SMS	You can enter up to four mobile wireless numbers that you en- tered previously at Setup – SMS Unit; each number is separated with the ampersand character "&" (e.g. 1&2&3&4).
Send E-Mail	You can enter up to four e-mail addresses that you entered previously at Setup – E-Mail (SMTP); each number is sepa- rated with the ampersand char- acter "&" (e.g. 1&2&3&4).
Accept	Accept the changes.
Reset	Reset all settings to the values saved most recently; any changes are not accepted.

7.7.5 Configuring the Humidity Sensor

You configure the humidity sensor (DK 7320.510) as follows. The humidity is specified as relative humidity (% rH).

Navigation				
Main menu – Setup – Click the sensor name				
Parameter Explanation				
1 n	Connection number of the sen- sor.			
Туре	Sensor type. Will be detected automatically.			
Sensor Status	Measured humidity and sensor status. Green = OK, yellow = warning, red = alarm.			
Message Text	The message text which is also transferred when a warn- ing/alarm message is sent. Enter here a designation that uniquely identifies your sensor, e.g. "Air humidity rack 1".			
Setpoint High	Humidity limit which when over- shot causes an alarm message to be issued.			
Setpoint Warn- ing	Humidity limit which when over- shot causes a warning mes- sage to be issued.			
Setpoint Low	Humidity limit which when un- dershot causes an alarm mes- sage to be issued.			
Alarm Relay	Whether (enable) or not (dis- able) an alarm relay should switch in the event of a warn- ing/alarm.			

EN

Alarm Beeper	Whether (enable) or not (dis- able) an audio signal should be issued in the event of a warn- ing/alarm.
Alarm Reset	Should a warning/alarm be acknowledged automatically (Auto) or does it need to be acknowledged by the adminis- trator (Manual).
Trap Receiver	Specify which of the entered trap receivers is to be sent warning/alarm messages. Enter the trap receivers at 7.3.2 Configuring the Trap Receiver.
Scheduled Alarm Off	Specify which alarm configura- tion should be enabled or dis- abled. The individual functions can be setup from the "Setup – Timer" menu item.
Send SMS	You can enter up to four mobile wireless numbers that you en- tered previously at Setup – SMS Unit; each number is separated with the ampersand character "&" (e.g. 1&2&3&4).
Send E-Mail	You can enter up to four e-mail addresses that you entered previously at Setup – E-Mail (SMTP); each number is sepa- rated with the ampersand char- acter "&" (e.g. 1&2&3&4).
Accept	Accept the changes.
Reset	Reset all settings to the values saved most recently; any changes are not accepted.

7.7.6 Configuring the Analogue Sensor Input Module

You configure the analogue sensor input module (DK 7320.520) as follows. The individual values are specified as percentage.

Navigation			
Main menu – Setup – Click the sensor name			
Parameter Explanation			
1 n	Connection number of the sensor.		
Туре	Sensor type. Will be detected automatically.		
Sensor Status	Measured input current (as percentage) and sensor status. Green = OK, yellow = warning,		

	red = alarm.				
Message Text	The message text which is also transferred when a warn- ing/alarm message is sent. Enter here a designation that uniquely identifies your sensor, e.g. "Analogue sensor rack 1".				
Setpoint High	Input current limit which when overshot causes an alarm mes- sage to be issued.				
Setpoint Warn- ing	Input current limit which when overshot causes a warning message to be issued.				
Setpoint Low	Input current limit which when undershot causes an alarm message to be issued.				
Alarm Relay	Whether (enable) or not (dis- able) an alarm relay should switch in the event of a warn- ing/alarm.				
Alarm Beeper	Whether (enable) or not (dis- able) an audio signal should be issued in the event of a warn- ing/alarm.				
Alarm Reset	Should a warning/alarm be acknowledged automatically (Auto) or does it need to be acknowledged by the adminis- trator (Manual).				
Trap Receiver	Specify which of the entered trap receivers is to be sent warning/alarm messages. Enter the trap receivers at 7.3.2 Configuring the Trap Receiver.				
Scheduled Alarm Off	Specify which alarm configura- tion should be enabled or dis- abled. The individual functions can be setup from the "Setup – Timer" menu item.				
Send SMS	You can enter up to four mobile wireless numbers that you en- tered previously at Setup – SMS Unit; each number is separated with the ampersand character "&" (e.g. 1&2&3&4).				
Send E-Mail	You can enter up to four e-mail addresses that you entered previously at Setup – E-Mail (SMTP); each number is sepa- rated with the ampersand char- acter "&" (e.g. 1&2&3&4).				
Accept	Accept the changes.				
Reset	Reset all settings to the values saved most recently; any				

EN

changes are not accepted.

7.7.7 Configuring the Access Sensor

You configure the access sensor (DK 7320.530) as follows:

Navigation				
Main menu – Setup – Click the sensor name				
Parameter	Explanation			
1 n	Connection number of the sen- sor.			
Туре	Sensor type. Will be detected automatically.			
Sensor Status	Access sensor status; green = OK, red = alarm.			
Message Text	The message text which is also transferred when a warn- ing/alarm message is sent. Enter here a designation that uniquely identifies your sensor, e.g. "Access sensor rack 1".			
Alarm Relay	Whether (enable) or not (dis- able) an alarm relay should switch in the event of a warn- ing/alarm.			
Alarm Beeper	Whether (enable) or not (dis- able) an audio signal should be issued in the event of a warn- ing/alarm.			
Alarm Reset	Should a warning/alarm be acknowledged automatically (Auto) or does it need to be acknowledged by the adminis- trator (Manual).			
Trap Receiver	Specify which of the entered trap receivers is to be sent warning/alarm messages. Enter the trap receivers at 7.3.2 Configuring the Trap Receiver.			
Scheduled Alarm Off	Specify which alarm configura- tion should be enabled or dis- abled. The individual functions can be setup from the "Setup – Timer" menu item.			
Send SMS	You can enter up to four mobile wireless numbers that you en- tered previously at Setup – SMS Unit; each number is separated with the ampersand character "&" (e.g. 1&2&3&4).			
Send E-Mail	You can enter up to four e-mail addresses that you entered			

	previously at Setup – E-Mail (SMTP); each number is sepa- rated with the ampersand char- acter "&" (e.g. 1&2&3&4).
Accept	Accept the changes.
Reset	Reset all settings to the values saved most recently; any changes are not accepted.

7.7.8 Configuring the Vandalism Sensor

You configure the vandalism sensor (DK 7320.540) as follows. The individual values are specified as pulses.

Navigation				
Main menu – Setup – Click the sensor name				
Parameter	Explanation			
1 n	Connection number of the sen- sor.			
Туре	Sensor type. Will be detected automatically.			
Sensor Status	Measured pulses and sensor status. Green = OK, yellow = warning, red = alarm.			
Message Text	The message text which is also transferred when a warn- ing/alarm message is sent. Enter here a designation that uniquely identifies your sensor, e.g. "Vandalism sensor rack 1".			
Setpoint High	Pulse limit which when overshot causes an alarm message to be issued.			
Setpoint Warn- ing	Pulse limit which when overshot causes a warning message to be issued.			
Setpoint Low	Pulse limit which when under- shot causes an alarm message to be issued.			
Alarm Relay	Whether (enable) or not (dis- able) an alarm relay should switch in the event of a warn- ing/alarm.			
Alarm Beeper	Whether (enable) or not (dis- able) an audio signal should be issued in the event of a warn- ing/alarm.			
Alarm Reset	Should a warning/alarm be acknowledged automatically (Auto) or does it need to be acknowledged by the adminis-			

	trator (Manual).		
Trap Receiver	Specify which of the entered trap receivers is to be sent warning/alarm messages. Enter the trap receivers at 7.3.2 Configuring the Trap Receiver.		
Scheduled Alarm Off	Specify which alarm configura- tion should be enabled or dis- abled. The individual functions can be setup from the "Setup – Timer" menu item.		
Send SMS	You can enter up to four mobile wireless numbers that you en- tered previously at Setup – SMS Unit; each number is separated with the ampersand character "&" (e.g. 1&2&3&4).		
Send E-Mail	You can enter up to four e-mail addresses that you entered previously at Setup – E-Mail (SMTP); each number is sepa- rated with the ampersand char- acter "&" (e.g. 1&2&3&4).		
Accept	Accept the changes.		
Reset	Reset all settings to the values saved most recently; any changes are not accepted.		

7.7.9 Configuring the Air Flow Sensor

You configure the air flow sensor (DK 7320.550) as follows. Only the status of the sensor is specified.

Navigation			
Main menu – Setup – Click the sensor name			
Parameter	Explanation		
1 n	Connection number of the sen- sor.		
Туре	Sensor type. Will be detected automatically.		
Sensor Status	s Air flow status and sensor status. Green = OK, red = a- larm.		
Message Text	The message text which is also transferred when a warning message is sent. Enter here a designation that uniquely identi- fies your sensor, e.g. "Air flow rack 1".		
Alarm Relay	Whether (enable) or not (dis- able) an alarm relay should switch in the event of an alarm.		

Alarm Beeper	Whether (enable) or not (dis- able) an audio signal should be issued in the event of an alarm.
Alarm Reset	Should an alarm be acknowl- edged automatically (Auto) or does it need to be acknowl- edged by the administrator (Manual).
Trap Receiver	Specify which of the entered trap receivers is to be sent alarm messages. Enter the trap receivers at 7.3.2 Configuring the Trap Receiver.
Scheduled Alarm Off	Specify which alarm configura- tion should be enabled or dis- abled. The individual functions can be setup from the "Setup – Timer" menu item.
Send SMS	You can enter up to four mobile wireless numbers that you en- tered previously at Setup – SMS Unit; each number is separated with the ampersand character "&" (e.g. 1&2&3&4).
Send E-Mail	You can enter up to four e-mail addresses that you entered previously at Setup – E-Mail (SMTP); each number is sepa- rated with the ampersand char- acter "&" (e.g. 1&2&3&4).
Accept	Accept the changes.
Reset	Reset all settings to the values saved most recently; any changes are not accepted.

7.7.10 Configuring the Smoke Detector

You configure the smoke detector (DK 7320.560) as follows. Only the status of the sensor is specified.

Navigation			
Main menu – Setup – Click the sensor name			
Parameter Explanation			
1 n	Connection number of the sen- sor.		
Туре	Sensor type. Will be detected automatically.		
Sensor Status	Smoke detector status and sensor status. Green = OK, red = alarm.		
Message Text	The message text which is also transferred when a warning message is sent. Enter here a		

EN

		designation that uniquely identi- fies your sensor, e.g. "Smoke detector rack 1".		Sensor Status	Motion detector status and sensor status. Green = OK = alarm.	
	Alarm Relay	Whether (enable) or not (dis- able) an alarm relay should switch in the event of an alarm.		Message Text	The message text which is transferred when a warning message is sent. Enter her	
	Alarm Beeper	Whether (enable) or not (dis- able) an audio signal should be issued in the event of an alarm.			designation that uniquely id fies your sensor, e.g. "Moti detector rack 1".	
	Alarm Reset	Should an alarm be acknowl- edged automatically (Auto) or does it need to be acknowl-		Alarm Relay	Whether (enable) or not (di able) an alarm relay should switch in the event of an ala	
	Tran Peceiver	edged by the administrator (Manual).		Alarm Beeper Whether (enable) or able) an audio signa issued in the event of	Whether (enable) or not (di able) an audio signal shoul issued in the event of an al	
		trap receivers is to be sent alarm messages. Enter the trap receivers at 7.3.2 Configuring the Trap Receiver.		Alarm Reset	Should an alarm be acknow edged automatically (Auto) does it need to be acknowledged by the administrator	
	Scheduled Alarm Off	Iled OffSpecify which alarm configura- tion should be enabled or dis- abled. The individual functions can be setup from the "Setup – Timer" menu item.SMSYou can enter up to four mobile wireless numbers that you en- tered previously at Setup – SMS Unit; each number is separated with the ampersand character "&" (e.g. 1&2&3&4).		Tran Peceiver	(Manual).	
-				hap neceiver	trap receivers is to be sent alarm messages. Enter the receivers at 7.3.2 Configuri	
	Send SMS			Scheduled Alarm Off	Specify which alarm configuent tion should be enabled or de abled. The individual function can be setup from the "Setuent Timer" menu item.	
	Send E-Mail	You can enter up to four e-mail addresses that you entered previously at Setup – E-Mail (SMTP); each number is sepa- rated with the ampersand char- acter "&" (e.g. 1&2&3&4).		Send SMS	You can enter up to four me wireless numbers that you tered previously at Setup – SMS Unit; each number is separated with the ampersa character "&" (e.g. 1&2&3&	
	Accept	Accept the changes.		Send E-Mail	You can enter up to four e-	
	Reset	Reset all settings to the values saved most recently; any changes are not accepted.			previously at Setup – E-Ma (SMTP); each number is se	

7.7.11 Configuring the Motion Detector

You configure the motion detector (DK 7320.570) as follows. Only the status of the sensor is specified.

Navigation	
Main menu – Setup – Click the sensor name	
Parameter	Explanation
1 n	Connection number of the sen- sor.
Туре	Sensor type. Will be detected automatically.

	sensor status. Green = OK, red = alarm.
Message Text	The message text which is also transferred when a warning message is sent. Enter here a designation that uniquely identi- fies your sensor, e.g. "Motion detector rack 1".
Alarm Relay	Whether (enable) or not (dis- able) an alarm relay should switch in the event of an alarm.
Alarm Beeper	Whether (enable) or not (dis- able) an audio signal should be issued in the event of an alarm.
Alarm Reset	Should an alarm be acknowl- edged automatically (Auto) or does it need to be acknowl- edged by the administrator (Manual).
Trap Receiver	Specify which of the entered trap receivers is to be sent alarm messages. Enter the trap receivers at 7.3.2 Configuring the Trap Receiver.
Scheduled Alarm Off	Specify which alarm configura- tion should be enabled or dis- abled. The individual functions can be setup from the "Setup – Timer" menu item.
Send SMS	You can enter up to four mobile wireless numbers that you en- tered previously at Setup – SMS Unit; each number is separated with the ampersand character "&" (e.g. 1&2&3&4).
Send E-Mail	You can enter up to four e-mail addresses that you entered previously at Setup – E-Mail (SMTP); each number is sepa- rated with the ampersand char- acter "&" (e.g. 1&2&3&4).
Accept	Accept the changes.
Reset	Reset all settings to the values saved most recently; any changes are not accepted.

7.7.12 Configuring the Digital Input Module

You configure the digital input module (DK 7320.580) as follows. Only the status of the sensor is specified.

Navigation	
Main menu – Se	tup – Click the sensor name
Parameter	Explanation
1 n	Connection number of the sensor.
Туре	Sensor type. Will be detected automatically.
Sensor Status	Input status and sensor status. Green = OK, red = alarm.
Message Text	The message text which is also transferred when a warning message is sent. Enter here a designation that uniquely identi- fies your sensor, e.g. "Digital input rack 1".
Alarm Relay	Whether (enable) or not (dis- able) an alarm relay should switch in the event of an alarm.
Alarm Beeper	Whether (enable) or not (dis- able) an audio signal should be issued in the event of an alarm.
Alarm Reset	Should an alarm be acknowl- edged automatically (Auto) or does it need to be acknowl- edged by the administrator (Manual).
Trap Receiver	Specify which of the entered trap receivers is to be sent alarm messages. Enter the trap receivers at 7.3.2 Configuring the Trap Receiver.
Scheduled Alarm Off	Specify which alarm configura- tion should be enabled or dis- abled. The individual functions can be setup from the "Setup – Timer" menu item.
Send SMS	You can enter up to four mobile wireless numbers that you en- tered previously at Setup – SMS Unit; each number is separated with the ampersand character "&" (e.g. 1&2&3&4).
Send E-Mail	You can enter up to four e-mail addresses that you entered previously at Setup – E-Mail (SMTP); each number is sepa- rated with the ampersand char- acter "&" (e.g. 1&2&3&4).
Accept	Accept the changes.
Reset	Reset all settings to the values saved most recently; any changes are not accepted.

7.7.13 Configuring the Digital Output Relay Module

You configure the digital output relay module (DK 7320.590) as follows. Only the status of the sensor is specified.

Navigation	
Main menu – Setup – Click the sensor name	
Parameter	Explanation
1 n	Connection number of the sen- sor.
Туре	Sensor type. Will be detected automatically.
Output Status	Relay output status; enabled = on, disabled = off.
Message Text	The message text which is also transferred when a warning message is sent. Enter here a designation that uniquely identi- fies your sensor, e.g. "Digital output rack 1".
Delay	Delay time for next switch on or off. 0 s = no release time; 999 s = 999 seconds release time.
Timeout	Module behaviour for failure of the PUII provided the module itself is still being supplied with power: stay = return to the original status after expiration of the time; switch off = the output is switched off after expiration of the time; switch on = the relay is switched on after expiration of the time.
Trap Receiver	Specify which of the entered trap receivers is to be sent status messages. Enter the trap receivers at 7.3.2 Configuring the Trap Receiver.
Send SMS	You can enter up to four mobile wireless numbers that you en- tered previously at Setup – SMS Unit; each number is separated with the ampersand character "&" (e.g. 1&2&3&4).
Send E-Mail	You can enter up to four e-mail addresses that you entered previously at Setup – E-Mail (SMTP); each number is sepa- rated with the ampersand char- acter "&" (e.g. 1&2&3&4).

the second s	
Combinations	Configure the switching combi- nations (see 7.7.14 Configuring Switching Combinations for the Digital Relay Output Module).
Switch Output	Manual enable (On) or disable (Off).
Accept	Accept the changes.
Reset	Reset all settings to the values saved most recently; any changes are not accepted.

7.7.14 Configuring Switching Combinations for the Digital Relay Output Module

You configure the switching combination for the digital relay output module (DK 7320.590) as follows. Various switching combinations can be set.

Navigation

Main menu – Setup – Click the sensor name – Switching combinations

Parameter	Explanation
If status of	Select the first sensor for the switching combination.
is	Select the first sensor status for a switching operation.
and/or	Select an "and" or "or" opera- tion.
status of	Select the second sensor for the switching combination.
is	Select the second sensor status for a switching operation.
Thenoutput	Select the switching state when the switching combination is satisfied. Switch off = deacti- vate relay output; switch on = activate relay output.
Accept	Accept the changes.
Reset	Reset all settings to the values saved most recently; any changes are not accepted.

7.7.15 Configuring the Voltage Monitor

You configure the voltage monitor (DK 7320.600) as follows. Only the status of the sensor is specified.

Navigation

Main menu - Setup - Click the sensor name

Parameter	Explanation
1 n	Connection number of the sensor.
Туре	Sensor type. Will be detected automatically.
Sensor Status	Input state and sensor status. Green = OK, red = alarm.
Message Text	The message text which is also transferred when a warning message is sent. Enter here a designation that uniquely identi- fies your sensor, e.g. "VltgRack01".
Alarm Relay	Whether (enable) or not (dis- able) an alarm relay should switch in the event of an alarm.
Alarm Beeper	Whether (enable) or not (dis- able) an audio signal should be issued in the event of an alarm.
Alarm Reset	Should an alarm be acknowl- edged automatically (Auto) or does it need to be acknowl- edged by the administrator (Manual).
Trap Receiver	Specify which of the entered trap receivers is to be sent alarm messages. Enter the trap receivers at 7.3.2 Configuring the Trap Receiver.
Scheduled Alarm Off	Specify which alarm configura- tion should be enabled or dis- abled. The individual functions can be setup from the "Setup – Timer" menu item.
Send SMS	You can enter up to four mobile wireless numbers that you en- tered previously at Setup – SMS Unit; each number is separated with the ampersand character "&" (e.g. 1&2&3&4).
Send E-Mail	You can enter up to four e-mail addresses that you entered previously at Setup – E-Mail (SMTP); each number is sepa- rated with the ampersand char- acter "&" (e.g. 1&2&3&4).
Accept	Accept the changes.
Reset	Reset all settings to the values saved most recently; any changes are not accepted.

7.7.16 Configuring the Voltage Monitoring for the Voltage Monitor with IEC Switch Output

You configure the voltage monitor with IEC switch output (DK 7320.610) as follows. The individual values are specified in volts.

Navigation	
Main menu – Setup – Click the sensor name	
Parameter	Explanation
1 n	Connection number of the sen- sor.
Туре	Sensor type. Will be detected automatically.
Sensor Status	Measured voltage and sensor status. Green = OK, red = a- larm.
Message Text	The message text which is also transferred when a warning message is sent. Enter here a designation that uniquely identi- fies your sensor, e.g. "VltgRack01".
Setpoint High	Voltage limit which when over- shot causes an alarm message to be issued.
Setpoint Warn- ing	Voltage limit which when over- shot causes a warning mes- sage to be issued.
Setpoint Low	Voltage limit which when un- dershot causes an alarm mes- sage to be issued.
Alarm Relay	Whether (enable) or not (dis- able) an alarm relay should switch in the event of a warn- ing/alarm.
Alarm Beeper	Whether (enable) or not (dis- able) an audio signal should be issued in the event of a warn- ing/alarm.
Alarm Reset	Should an alarm be acknowl- edged automatically (Auto) or does it need to be acknowl- edged by the administrator (Manual).
Trap Receiver	Specify which of the entered trap receivers is to be sent alarm messages. Enter the trap receivers at 7.3.2 Configuring the Trap Receiver.
Scheduled Alarm Off	Specify which alarm configura- tion should be enabled or dis- abled. The individual functions

	can be setup from the "Setup – Timer" menu item.
Send SMS	You can enter up to four mobile wireless numbers that you en- tered previously at Setup – SMS Unit; each number is separated with the ampersand character "&" (e.g. 1&2&3&4).
Send E-Mail	You can enter up to four e-mail addresses that you entered previously at Setup – E-Mail (SMTP); each number is sepa- rated with the ampersand char- acter "&" (e.g. 1&2&3&4).
Accept	Accept the changes.
Reset	Reset all settings to the values saved most recently; any changes are not accepted.

7.7.17 Configuring the Switch Output for the Voltage Monitor with IEC Switch Output

You configure the switch output of the voltage monitor with IEC switch output (DK 7320.610) as follows. Only the status of the sensor is specified.

Navigation	
Main menu – Se	tup – Click the sensor name
Parameter	Explanation
1 n	Connection number of the sen- sor.
Туре	Sensor type. Will be detected automatically.
Output Status	Relay output status; enabled = on, disabled = off.
Message Text	The message text which is also transferred when a warning message is sent. Enter here a designation that uniquely identi- fies your sensor, e.g. "VltgRack01".
Delay	Delay time for next switch on or off. 0 s = no release time; 999 s = 999 seconds release time.
Timeout	Module behaviour for failure of the PUII provided the module itself is still being supplied with power: stay = return to the original status after expiration of the time; switch off = the output is switched off after expiration of

	the time; switch on = the relay is switched on after expiration of the time.
Trap Receiver	Specify which of the entered trap receivers is to be sent status messages. Enter the trap receivers at 7.3.2 Configuring the Trap Receiver.
Send SMS	You can enter up to four mobile wireless numbers that you en- tered previously at Setup – SMS Unit; each number is separated with the ampersand character "&" (e.g. 1&2&3&4).
Send E-Mail	You can enter up to four e-mail addresses that you entered previously at Setup – E-Mail (SMTP); each number is sepa- rated with the ampersand char- acter "&" (e.g. 1&2&3&4).
Combinations	Configure the switching combi- nations (see 7.7.18 Configuring Switching Combinations for the Voltage Monitor with IEC Switch Output).
Switch Output	Manual enable (On) or disable (Off).
Accept	Accept the changes.
Reset	Reset all settings to the values saved most recently; any changes are not accepted.

7.7.18 Configuring the Switching Combinations for the Voltage Monitor with IEC Switch Output

You configure the switching combination for the voltage monitor with IEC switch output (DK 7320.610) as follows. Various switching combinations can be set.

Navigation	
Main menu – Setup – Click the sensor name – Switching combinations	
Parameter	Explanation
If status of	Select the first sensor for the switching combination.
is	Select the first sensor status for a switching operation.
and/or	Select an "and" or "or" opera- tion.

status of	Select the second sensor for the switching combination.
is	Select the second sensor status for a switching operation.
Thenoutput	Select the switching status when the switching combination is satisfied. switch off = disable switch output; switch on = en- able switch output.
Accept	Accept the changes.
Reset	Reset all settings to the values saved most recently; any changes are not accepted.

7.7.19 Configuring the Voltage Monitoring for the Voltage Monitor with 16 A Switch Output

You configure the voltage monitor with 16 A switch output (DK 7320.611) as follows. The individual values are specified in volts.

Navigation		
Main menu – Setup – Click the sensor name		
Parameter	Explanation	
1 n	Connection number of the sensor.	
Туре	Sensor type. Will be detected automatically.	
Sensor Status	Measured voltage and sensor status. Green = OK, yellow = warning, red = alarm.	
Message Text	The message text which is also transferred when a warn- ing/alarm message is sent. Enter here a designation that uniquely identifies your sensor, e.g. "VltgRack01".	
Setpoint High	Voltage limit which when over- shot causes an alarm message to be issued.	
Setpoint Warn- ing	Voltage limit which when over- shot causes a warning mes- sage to be issued.	
Setpoint Low	Voltage limit which when un- dershot causes an alarm mes- sage to be issued.	
Alarm Relay	Whether (enable) or not (dis- able) an alarm relay should switch in the event of a warn- ing/alarm.	

Alarm Beeper	Whether (enable) or not (dis- able) an audio signal should be issued in the event of a warn- ing/alarm.	_ Me	Message Text	The message text which is also transferred when a status mes- sage is sent. Enter here a des- ignation that uniquely identifies
Alarm Reset	Should a warning/alarm be acknowledged automatically (Auto) or does it need to be acknowledged by the adminis-		Delay	Delay time for next switch on or off. 0 s = no release time; 999 s = 999 seconds release time.
Trap Receiver	trator (Manual). Specify which of the entered trap receivers is to be sent warning/alarm messages. Enter the trap receivers at 7.3.2 Configuring the Trap Receiver.		Timeout	Module behaviour for failure of the PUII provided the module itself is still being supplied with power: stay = return to the original status after expiration of the
Scheduled Alarm Off	Specify which alarm configura- tion should be enabled or dis- abled. The individual functions can be setup from the "Setup – Timer" menu item.			time; switch off = the output is switched off after expiration of the time; switch on = the relay is switched on after expiration of the time.
Send SMS	You can enter up to four mobile wireless numbers that you en- tered previously at Setup – SMS Unit; each number is		Trap Receiver	Specify which of the entered trap receivers is to be sent status messages. Enter the trap receivers at 7.3.2 Configuring the Trap Receiver.
Send E-Mail	character "&" (e.g. 1&2&3&4). You can enter up to four e-mail addresses that you entered previously at Setup – E-Mail (SMTP); each number is sepa- rated with the ampersand char-		Send SMS	You can enter up to four mobile wireless numbers that you en- tered previously at Setup – SMS Unit; each number is separated with the ampersand character "&" (e.g. 1&2&3&4).
Accept	acter "&" (e.g. 1&2&3&4). Accept the changes.		Send E-Mail	You can enter up to four e-mail addresses that you entered
Reset	Reset all settings to the values saved most recently; any changes are not accepted.			(SMTP); each number is sepa- rated with the ampersand char- acter "&" (e.g. 1&2&3&4).
	•			

7.7.20 Configuring the Switch Output for the Voltage Monitor with 16 A **Switch Output**

You configure the switch output of the voltage monitor with 16 A switch output (DK 7320.611) as follows. Only the status of the sensor is specified.

Navigation		
Main menu – Setup – Click the sensor name		
Parameter	Explanation	
1 n	Connection number of the sensor.	
Туре	Sensor type. Will be detected automatically.	
Output Status	Relay output status; enabled = on, disabled = off.	

99 s of le vith is of ay on d trap ٦g bile enand 4). nail pahar-Configure the switching combi-Combinations nations (see 7.7.21 Configuring Switching Combinations for the Voltage Monitor with 16 A Switch Output). Switch Output Manual enable (On) or disable (Off). Accept Accept the changes. Reset all settings to the values Reset saved most recently; any changes are not accepted.

7.7.21 Configuring the Switching Combinations for the Voltage Monitor with 16 A Switch Output

You configure the switching combination for the voltage monitor with 16 A switch output

CMC-TC Processing Unit II

(DK 7320.611) as nations can be set	follows. Various switching combi- t.	
Navigation		
Main menu – Setup – Click the sensor name – Switching combinations		
Parameter	Explanation	
If status of	Select the first sensor for the switching combination.	

is	Select the first sensor status for a switching operation.
and/or	Select an "and" or "or" opera- tion.
status of	Select the second sensor for the switching combination.
is	Select the second sensor status for a switching operation.
Thenoutput	Select the switching status when the switching combination is satisfied. switch off = disable switch output; switch on = en- able switch output.
Accept	Accept the changes.
Reset	Reset all settings to the values saved most recently; any changes are not accepted.

7.7.22 Configuring the 48 V Voltage Monitor

You configure the 48 V voltage monitor (DK 7320.620) as follows. Only the status of the sensor is specified.

Navigation		
Main menu – Setup – Click the sensor name		
Parameter	Explanation	
1 n	Connection number of the sen- sor.	
Туре	Sensor type. Will be detected automatically.	
Sensor Status	48 V voltage monitor state and sensor status. Green = OK, red = alarm.	
Message Text	The message text which is also transferred when a warn- ing/alarm message is sent. Enter here a designation that uniquely identifies your sensor, e.g. "48 V VltgRack01".	
Alarm Relay	Whether (enable) or not (dis-	

	able) an alarm relay should switch in the event of an alarm.
Alarm Beeper	Whether (enable) or not (dis- able) an audio signal should be issued in the event of an alarm.
Alarm Reset	Should an alarm be acknowl- edged automatically (Auto) or does it need to be acknowl- edged by the administrator (Manual).
Trap Receiver	Specify which of the entered trap receivers is to be sent alarm messages. Enter the trap receivers at 7.3.2 Configuring the Trap Receiver.
Scheduled Alarm Off	Specify which alarm configura- tion should be enabled or dis- abled. The individual functions can be setup from the "Setup – Timer" menu item.
Send SMS	You can enter up to four mobile wireless numbers that you en- tered previously at Setup – SMS Unit; each number is separated with the ampersand character "&" (e.g. 1&2&3&4).
Send E-Mail	You can enter up to four e-mail addresses that you entered previously at Setup – E-Mail (SMTP); each number is sepa- rated with the ampersand char- acter "&" (e.g. 1&2&3&4).
Accept	Accept the changes.
Reset	Reset all settings to the values saved most recently; any changes are not accepted.

7.7.23 Configuring the Leakage Sensor

You configure the leakage sensor (DK 7320.630) as follows. Only the status of the sensor is specified.

Navigation		
Main menu – Setup – Click the sensor name		
Parameter	Explanation	
1 n	Connection number of the sen- sor.	
Туре	Sensor type. Will be detected automatically.	
Sensor Status	Smoke detector status and sensor status. Green = OK, red = alarm.	

Message Text	The message text which is also transferred when a warning message is sent. Enter here a designation that uniquely identi- fies your sensor, e.g. "Leakage Rack01".
Alarm Relay	Whether (enable) or not (dis- able) an alarm relay should switch in the event of an alarm.
Alarm Beeper	Whether (enable) or not (dis- able) an audio signal should be issued in the event of an alarm.
Alarm Reset	Should an alarm be acknowl- edged automatically (Auto) or does it need to be acknowl- edged by the administrator (Manual).
Trap Receiver	Specify which of the entered trap receivers is to be sent alarm messages. Enter the trap receivers at 7.3.2 Configuring the Trap Receiver.
Scheduled Alarm Off	Specify which alarm configura- tion should be enabled or dis- abled. The individual functions can be setup from the "Setup – Timer" menu item.
Send SMS	You can enter up to four mobile wireless numbers that you en- tered previously at Setup – SMS Unit; each number is separated with the ampersand character "&" (e.g. 1&2&3&4).
Send E-Mail	You can enter up to four e-mail addresses that you entered previously at Setup – E-Mail (SMTP); each number is sepa- rated with the ampersand char- acter "&" (e.g. 1&2&3&4).
Accept	Accept the changes.
Reset	Reset all settings to the values saved most recently; any changes are not accepted.

1 n	Connection number of the sen- sor.
Туре	Sensor type. Will be detected automatically.
Sensor Status	Measured loudness as per- centage and sensor status. Green = OK, yellow = warning, red = alarm.
Message Text	The message text which is also transferred when a warn- ing/alarm message is sent. Enter here a designation that uniquely identifies your sensor, e.g. "Acoustic Rack01".
Setpoint High	Loudness limit (as percentage) which when overshot causes an alarm message to be issued.
Setpoint Warn- ing	Loudness limit (as percentage) which when overshot causes a warning message to be issued.
Setpoint Low	Loudness limit (as percentage) which when undershot causes an alarm message to be issued.
Alarm Relay	Whether (enable) or not (dis- able) an alarm relay should switch in the event of a warn- ing/alarm.
Alarm Beeper	Whether (enable) or not (dis- able) an audio signal should be issued in the event of a warn- ing/alarm.
Alarm Reset	Should a warning/alarm be acknowledged automatically (Auto) or does it need to be acknowledged by the adminis- trator (Manual).
Trap Receiver	Specify which of the entered trap receivers is to be sent warning/alarm messages. Enter the trap receivers at 7.3.2 Configuring the Trap Receiver.
Scheduled Alarm Off	Specify which alarm configura- tion should be enabled or dis- abled. The individual functions can be setup from the "Setup – Timer" menu item.
Send SMS	You can enter up to four mobile wireless numbers that you en- tered previously at Setup – SMS Unit; each number is separated with the ampersand character "&" (e.g. 1&2&3&4).
Send E-Mail	You can enter up to four e-mail addresses that you entered

7.7.24 Configuring the Acoustic Sensor

You configure the acoustic sensor (DK 7320.640) as follows. Various limit values can be entered as percentages.

Navigation		
Main menu – Setup – Click the sensor name		
Parameter	Explanation	

EN

	previously at Setup – E-Mail (SMTP); each number is sepa- rated with the ampersand char- acter "&" (e.g. 1&2&3&4).
Accept	Accept the changes.
Reset	Reset all settings to the values saved most recently; any changes are not accepted.

7.7.25 Configuring the Fan Control System (FCS)

You configure the FCS (DK 7320.810) as follows:

Navigation	
Main menu – Setup – Click the first sensor name	
Parameter	Explanation
1n	Connection number of the sen- sor.
Туре	Sensor type. Will be detected automatically.
Sensor Status	Measured temperature and sensor status. Green = OK, yellow = warning, red = alarm.
Message Text	The message text which is also transferred when a warn- ing/alarm message is sent. Enter here a designation that uniquely identifies your sensor, e.g. "FCS-Temp Rack01".
Setpoint High	Temperature limit which when overshot causes an alarm mes- sage to be issued.
Setpoint	Temperature limit above which the fan operates at 100% power.
Setpoint Low	Temperature limit which when undershot causes an alarm message to be issued.
Alarm Relay	Whether (enable) or not (dis- able) an alarm relay should switch in the event of an alarm.
Alarm Beeper	Whether (enable) or not (dis- able) an audio signal should be issued in the event of an alarm.
Alarm Reset	Should an alarm be acknowl- edged automatically (Auto) or does it need to be acknowl- edged by the administrator (Manual).
Trap Receiver	Specify which of the entered trap receivers is to be sent

	alarm messages. Enter the trap receivers at 7.3.2 Configuring the Trap Receiver.
Scheduled Alarm Off	Specify which alarm configura- tion should be enabled or dis- abled. The individual functions can be setup from the "Setup – Timer" menu item.
Send SMS	You can enter up to four mobile wireless numbers that you en- tered previously at Setup – SMS Unit; each number is separated with the ampersand character "&" (e.g. 1&2&3&4).
Send E-Mail	You can enter up to four e-mail addresses that you entered previously at Setup – E-Mail (SMTP); each number is sepa- rated with the ampersand char- acter "&" (e.g. 1&2&3&4).
Accept	Accept the changes.
Reset	Reset all settings to the values saved most recently; any changes are not accepted.

Click tab 2 to continue the configuration.

Navigation	
Main menu – Setup – Click the second sensor name	
Parameter	Explanation
2	Connection number of the sen- sor.
Туре	Sensor type. Will be detected automatically.
Sensor Status	Sensor status. Green = OK, red = alarm.
Message Text	The message text which is also transferred when a warn- ing/alarm message is sent. Enter here a designation that uniquely identifies your sensor, e.g. "FCS-Fan Rack01".
Accept	Accept the changes.
Reset	Reset all settings to the values saved most recently; any changes are not accepted.

Click tab 3 to continue the configuration.

Navigation

Main menu - Setup - Click the third sensor name

Parameter	Explanation
3	Connection number of the sen- sor.
Туре	Sensor type. Will be detected automatically.
Fan Status	Sensor status. Green = OK, red = alarm, grey = fan not con- nected.
Message Text	The message text which is also transferred when a warning message is sent. Enter here a designation that uniquely identi- fies your sensor, e.g. "FCS fan rack 1".
Alarm Relay	Whether (enable) or not (dis- able) an alarm relay should switch in the event of an alarm.
Alarm Beeper	Whether (enable) or not (dis- able) an audio signal should be issued in the event of an alarm.
Alarm Reset	Should an alarm be acknowl- edged automatically (Auto) or does it need to be acknowl- edged by the administrator (Manual).
Trap Receiver	Specify which of the entered trap receivers is to be sent alarm messages. Enter the trap receivers at 7.3.2 Configuring the Trap Receiver.
Scheduled Alarm Off	Specify which alarm configura- tion should be enabled or dis- abled. The individual functions can be setup from the "Setup – Timer" menu item.
Send SMS	You can enter up to four mobile wireless numbers that you en- tered previously at Setup – SMS Unit; each number is separated with the ampersand character "&" (e.g. 1&2&3&4).
Send E-Mail	You can enter up to four e-mail addresses that you entered previously at Setup – E-Mail (SMTP); each number is sepa- rated with the ampersand char- acter "&" (e.g. 1&2&3&4).
Accept	Accept the changes.
Reset	Reset all settings to the values saved most recently; any changes are not accepted.

7.7.26 Configuring the Fan Alarm Sys- tem (FAS)
You configure the FAS (DK 7320.811) as follows:
Newlanding

Navigation		
Main menu – Setup – Click the first sensor name		
Parameter	Explanation	
1n	Connection number of the sensor.	
Туре	Sensor type. Will be detected automatically.	
Sensor Status	Sensor status. Green = OK, red = alarm.	
Message Text	The message text which is also transferred when a warning message is sent. Enter here a designation that uniquely identi- fies your sensor, e.g. "FAS-Fan Rack01".	
Alarm Relay	Whether (enable) or not (dis- able) an alarm relay should switch in the event of an alarm.	
Alarm Beeper	Whether (enable) or not (dis- able) an audio signal should be issued in the event of an alarm.	
Alarm Reset	Should an alarm be acknowl- edged automatically (Auto) or does it need to be acknowl- edged by the administrator (Manual).	
Trap Receiver	Specify which of the entered trap receivers is to be sent alarm messages. Enter the trap receivers at 7.3.2 Configuring the Trap Receiver.	
Scheduled Alarm Off	Specify which alarm configura- tion should be enabled or dis- abled. The individual functions can be setup from the "Setup – Timer" menu item.	
Send SMS	You can enter up to four mobile wireless numbers that you en- tered previously at Setup – SMS Unit; each number is separated with the ampersand character "&" (e.g. 1&2&3&4).	
Send E-Mail	You can enter up to four e-mail addresses that you entered previously at Setup – E-Mail (SMTP); each number is sepa- rated with the ampersand char- acter "&" (e.g. 1&2&3&4).	
Accept	Accept the changes.	

Reset

EN

Reset all settings to the values saved most recently; any changes are not accepted.

7.7.27 Wireless Sensors

The configuration of the wireless sensors corresponds to the configuration of the associated cableconnected sensor.

Wireless sensor type	see configura- tion in
Temperature	Section 7.7.4
Humidity	Section 7.7.5
Access	Section 7.7.7
Digital input	Section 7.7.12

The connection of the wireless sensors to the wireless I/O unit is described in detail in the Wireless I/O Unit manual (7320.240).

7.8 Access Using Telnet

You can also configure the Processing Unit using Telnet. This requires that you have used the terminal program to permit access using Telnet (see Section 7.3.18 Configuring the Telnet Access).

7.8.1 Login Using Telnet

The following section describes the access using Telnet under Windows.

- a. Open the input prompt and enter the command: telnet <IP-address>
- b. Confirm with Enter or Return.
- c. Enter for "Login" the Telnet login (factory setting: 'cmc'). Confirm with Enter or Return.
- d. Enter for "Password" the Telnet password (factory setting: 'cmc'). Confirm with Enter or Return.

7.8.2 Telnet Main Menu

After the login by Telnet, the same main menu as for access using HyperTerminal appears. Because all procedures are similar, refer to 7.

Note!

In addition to access using Telnet, an SSH client (e.g. Putty) can be used to make an encrypted access to the PUII configuration. Unlike the Telnet access, the SSH access cannot be disabled.

Performing a Software Update

Download from the internet page www.rimatrix5.com (Security) in the download area, the software update to your PC. Unzip the file into a separate folder, for example, with the name: puupdate.



- Open the input prompt and navigate to the folder that contains the unzipped software update.
- Enter the following command: update <IPaddress> (e.g. update 192.168.0.130).

The PUII must be reachable in the network with the specified IP address.

The file is now sent to the CMC-TC Processing Unit. This is displayed with several #-characters in the input prompt window.

The CMC-TC Processing Unit independently performs two restarts during the update process. This operation takes several minutes. Do not change anything on the CMC-TC. Do not disconnect the Processing Unit from the mains. Wait until the Operating LED lights again and the *Updating finished, login to Rittal CMC PU <IP-address> again* message appears.

7.10 Error Messages

Operating/Alarm LED off.

Cause	Correction
Power pack not con- nected.	Connect power pack.
Power pack defec- tive.	Replace the defective power pack with an op- erational one.
Power supply missing.	Establish the power supply.
PUII is booting.	Wait several minutes until the LED illuminates.

Link/Traffic LED off.

Cause	Correction
Network connection	Connect RJ-45 network

missing.	cable.
Incorrect IP address.	Check the IP address.
Incorrect subnet mask.	Check the subnet mask.
Incorrect gateway address.	Check the gateway ad- dress.

No access authorisation via Telnet.

Cause	Correction
Telnet access for the PUII blocked.	Use the HyperTerminal to activate the Telnet access.
Incorrect IP ad- dress entered.	Check the IP address.
Incorrect user name entered.	Check the user name.
Incorrect pass- word entered.	Check the password.

No access authorisation via browser.

Cause	Correction
Incorrect user name entered.	Check the user name.
Incorrect pass- word entered.	Check the password.

No access authorisation via HyperTerminal.

Cause	Correction
Incorrect user name entered.	Check the user name.
Incorrect pass- word entered.	Check the password.

No settings can be made via browser.

Cause	Correction
Web access set only to read au- thorisation.	Set the access authorisation using Hyperterminal or Tel- net in the Web Access menu item. Alternatively, the administra- tor must set the appropriate rights for the user in the web interface.

SNMP does not send (or traps do not arrive)

Cause	Correction
The entries for the read and	Use HyperTerminal or Telnet to compare the read and

write authorisa-
tion (read and
write community)
are not set cor-
rectly.write authorisation with the
management software.Trap receivers
have not been
entered.Check the trap receivers.

Sensor not detected or not displayed.

Cause	Correction
Sensor not con- tained in the software.	Perform a software update.
Sensor defective.	Replace sensor.
Sensor not con- nected.	Connect sensor; if neces- sary, remove and reinsert the sensor several times. It sometimes helps to briefly insert a different sensor in order to directly switch back to the first sensor.

7.11 Structure of the MIB of the Processing Unit

Only the device-typical part of the MIB of the Processing Unit (CMC-TC.MIB) is briefly described here. This part of the MIB in particular must satisfy the modular flexible system concept of the CMC-TC system. For this reason, the associated information that applies to the sensor units (e.g. I/O Unit, Access Unit, Climate Unit) and the downstream sensors or actuators is mainly shown in tables.

A table for the sensors, the outputs/actuators and the messages is provided for each connectable Sensor Unit. It is possible to connect up to four Sensor Units to the Processing Unit.

The number of table rows differs for each table type and depends on the maximum number of available ports for the Sensor Unit.

Overview of the maximum table entries for each Sensor Unit.

Sensor Unit	Sensors	Outputs	Messages
I/O Unit	4	4	4
Access Unit	8	6	4
FCS	3	1	3
RTT	40 (4 per device)		
RLCP	36	16	4

EN

Active	12 (3 per	12 (3 per	12 (3 per
PSM	module)	module)	module)
Climate Unit	2	1	3

Note that the number of possible sensors, outputs and messages is stored in the associated MIB variables.

Sensors:

🗰 130.0.2.218:cmcTcUnit2SensorTable							
C	🗴 👔 💽 🚺 🔽 🔊 🕅 🖓 🖓 🖓 🖓 🖓 🖓						
Instance	unit	unit2SensorType	unit2SensorText	unit2SensorStatus	unit2SensorValu		
1	1	notAvai(1)	not available	notAvail(1)	0		
🌚 2	2	temperature(10)	Temperature Sensor	ok[4]	26		
🕸 3	3	vibration(5)	Vandalism Sensor	ok(4)	0		
8 4	4	humidity(12)	Humidity Sensor	ok[4]	59		

Note!

The numbers in column 2 correspond to the port numbers of the I/O Unit. The sensors are assigned in accordance with their physical connection. This table does not show the outputs, refer to the next table.

Outputs:

C 20130.0.2.218 💌 🔊 🔽 Poll every 60 🛨 seconds 🗖 Mirror							
Instance	. U	unit20utputType	unit2OutputText	unit20utputStatus	unit2DutputValue	unit20	
🌚 1	1	universalOut(9)	Digital Output	off(5)	0	off(1)	
🕲 2	2	notAvai(1)	not available	notAvai(1)	0	off(1)	
😨 3	3	notAvai(1)	not available	notAvai(1)	0	off(1)	
و 🎃	4	notAvai(1)	not available	notAvai(1)	0	off(1)	

> Note!

The numbers in column 2 correspond to the port numbers of the I/O Unit. The shown outputs correspond to their physical connection on the port.

I	Messages:							
	ⅲ 130.0.	2.21	8:cmcTcUnit2MsgT	able				
	C 🖉	130	0.2.218		every 60 📩	seconds		
	Instance	u	unit2MsgText	unit2MsgStatus	unit2MsgRelay	unit2M sgB		
	1 🍪	1	Digital Output	setOff(9)	enable(2)	enable(2)		
	🎃 2	2	Temperature Sensor	ok(4)	enable(2)	enable(2)		
	🕹 З	3	Vandalism Sensor	ok(4)	enable(2)	enable(2)		
	@ 4	4	Humidity Sensor	ok(4)	enable(2)	enable(2)		

Note!

The numbers in column 2 correspond to the port numbers of the I/O Unit. The shown table entries correspond to the current status and the configuration settings for the port.

Representation of the table and the sample table entries of the Access Unit

Sensors:

田 130.0.2.218:cmcTcUnit3SensorTable							
C 🖉	130.0	.2.218	- 🔁 🔽 Poll ever	y 🐻 🕂 seconds	E Mirror		
Instance	uni	unit3SensorType	unit3SensorText	unit3SensorStatus	unit3SensorValu		
@ 1	1	lock(15)	Doorlock Sensor	ok(4)	1		
2	2	access[4]	Access Sensor	ok[4]	1		
🏶 3	3	notAvail(1)	not available	notAvai(1)	0		
و 🍘 4	4	access[4]	Access Sensor	ok[4]	1		
🌚 5	5	notAvail(1)	not available	notAvai(1)	0		
806	6	lock(15)	Doorlock Sensor	ok(4)	1		
2 7	7	readerKeypad(Cardreader/Keypad	off(5)	-1		
🏶 8	8	notAvail(1)	not available	notAvai(1)	0		

> Note!

Column 2 indicates to which port the accessory components are connected. Ports 1, 2, 3 and 7 correspond to door system 1; ports 4, 5, 6, and 8 correspond to door system 2.

Outputs:

# 130.0.2.218:cmcTcUnit3OutputTable								
C (8)	130	0.2.218		Poll every 60	seconds 🕅 Mi	nor		
Instance	u	unit3OutputType	unit3OutputText	unit3DutputStatus	unit3DutputValue	unit30ut		
🔁 1	1	doorLock[4]	Handle Lock	setOn(8)	1	lock(3)		
😨 2	2	notAvai(1)	not available	notAvail(1)	0	off(1)		
🌚 3	3	notAvai(1)	not available	notAvail(1)	0	off(1)		
छ 4	4	notAvai(1)	not available	notAvail(1)	0	off(1)		
😨 5	5	notAvai(1)	not available	notAvail[1]	0	off(1)		
🌞 6	6	doorLock[4]	Handle Lock	setOn(8)	1	off(1)		

>> Note!

Column 2 indicates the physical connection of the port assignment.

Messages:

Ⅲ 130.0.	2.21	8:emeTeUnit3M	sgT able			
C	130.	0.2.218	▼ 🔊 🔽 🔽	ry 60 🕂 secr	onds 🛛 🦳 Mirror	
Instance	ú.:.	unit3MsgText	unit3MsgStatus	unit3MsgRelay	unit3MsgBeeper	un
😵 1	1	Door Lock 1	locked(13)	enable(2)	enable(2)	en
🍄 2	2	Last Access 1	ok[4]	enable(2)	enable(2)	en
🍄 3	3	Door Lock 2	locked(13)	enable(2)	enable(2)	en
🍄 4	4	Last Access 2	un/ReaderKeypad(15)	enable(2)	enable(2)	en
	\sim	Notal				

The shown table entries correspond to the current status and the configuration settings for the door closing system 1 or 2.

Representation of the table and the sample table entries of the Climate Unit

Sensors:

C 🛞	130	0.2.218	•	Eoll every	60	seconds	<u>Minor</u>
Instance	u	unit1SensorType	. U	nit1SensorText	unit19	SensorStatus	unit1SensorV
😨 1	1	airFlow(8)	A	irflow Sensor	off(5)		0
🎃 2	2	temperature(10)	Т	emperature Sensor	ok(4)		26

> Note!

The numbers in column 2 correspond to the port numbers of the Climate Unit. The sensors are assigned in accordance with

their physical connection. This table does not show the outputs, refer to the next table.

module types. Additional details for the other module types are contained in the associated operating instructions.

Outputs: 130.0.2.218:cmcTcUnit1OutputTable seconds 🗖 Mirror C @ 130.0.2.218 - 🔁 🔽 Poll every 60 Instance u., unit10utputType unit10utputText unit10utputStatus unit10utputValue unit10ut fan(7) Ean setOff[7] n off(1) 1 Note!

Column 2 indicates the physical connection and the status of the port.

Notifications:

🕰 1

C 🕐	130.	0.2.218	- 🛛 🖂	Poll every 60	seconds	Г	Mirror
Instance	u	unit1MsgText	unit1MsgStatus	unit1MsgRelay	unit1MsgBee	sper	unit1Msg
😨 1	1	Airflow Sensor	ok(4)	enable(2)	enable(2)		enable(2)
ê 2	2	Temperatur 1	ok(4)	enable(2)	enable(2)		enable[2]
<u>ه</u> 3	3	Fan	setOff(9)	enable[2]	enable(2)		enable(2)

Note!

The numbers in column 2 correspond to the port numbers of the Climate Unit. The shown table entries correspond to the current status and the configuration settings for the port.

Representation of the general setup table and sample table entries

Another table provides the general setup settings shown below.

info 1 - 1 OID groups

😲 🖉 🚱 130.0.2.218	- 2	🛛 🔽 Poll every 60 🛨 seconds 🗖 Log 🧯
Name	Syntax	Value
🐡 cmcTcSetTempUnit.0	int32	celsius(1)
🐡 cmcTcSetBeeper.0	int32	off(1)
🐡 cmcTcQuitRelay.0	int32	disabled(1)
🐡 cmcTcLogicRelay.0	int32	closeAtAlarm(1)
🐡 cmcTcWebAccess.0	int32	fullAccess(2)
🐡 cmcTcSetupDate.0	octets	19.09.2002
🐡 cmcTcSetupTime.0	octets	15:18:14

7.12 ActivePSM (4-way)

The ActivePSM modules are available in various configurations.

PSM module	Configuration	Model No.
Active 4-way	4x C13	7865.200
Active 8-way	8x C13	7856.201
Active 8-way	8x C13 (19")	7200.001
Active 6-way	2x C13, 4x C19	7856.204
Active 6-way	2x C13, 4x earthing contacts	7856.203

The information for the ActivePSM (4-way) described here also applies to the four other active

7.12.1 Getting Acquainted with the Module Connections



ActivePSM (4-way) Fig. 34

Key:

- 0

- Fuse (10 A thermal circuit-breaker). 1
- 2 Display element (display of the actual current value).
- LED circuit 2 (depending on the installation position 3 and the configuration, the LED illuminates).
- 4 Connection to the Processing Unit or to the previous module.
- 5 LED circuit 1 (depending on the installation position and the configuration, the LED illuminates).
- 6 Pushbutton (used for configuring the module).
- Connection to the next module (up to four modules 7 can be cascaded).

7.12.2 Display and Operating Elements

2-digit 7-segment display, digit height 10 mm, colour: Red

The 7-segment display shows the actual current value. In setting mode, it also shows the settings parameter.

Up to a value of 9.9 A, the current is shown with one decimal place; above 10 A, the current is shown as integer value without decimal place.

In a fault situation, this display flashes.

Note that any changes made to the installation position also change the reading direction of the 7segment display.

Two 3-colour LEDs (green, orange, red), labelled "I" and "II".

These LEDs each flash in accordance with the installation position of the module.

Parameter	Explanation
Green	ОК
Orange	Warning, fuse triggered or mains voltage missing.
Red	Maximum current value ex- ceeded or minimum current value under- shot

Pushbutton:

The pushbutton is used to enter or change the limit values, the BUS address and for the fixed definition of the reading direction of the display.

Briefly pressing the pushbutton changes the setting value or the setting level.

Press the pushbutton for a longer period (approx. 4 seconds) to confirm the set value or the preselected setting level.

7.12.3 Displays

Parameter	Explanation
Flashing dis- play	Current not within the limits.
0.0 displayed	No consumers connected to the ActivePSM.
3.2, etc., dis- played	Consumers connected; their "consumed" current value is 3.2 A.
n.P. displayed	"No power" means that no power is supplied to the PSM bus or the fuse has deactivated the system.
LED display green	Everything OK.
LED display red	Value not within the limits.
LED display orange	No voltage or fuse has deacti- vated the system.

A detailed description of the setting menu for the ActivePSM is contained on the next page.

7.12.4 Setup Menu for the Local Pushbutton

Important parameters must be set for the initial commissioning of the active 4-way PSM. The following list displays how the active 4-way PSM is set.

Short press		= UP
Long press	(approx. 4 seconds)	= Enter

within the limite

Enter "L" dis-

play

play

play

play

"H" dis-

"A" dis-

"o" dis-

7.12.5 Connecting the ActivePSM to the CMC-TC

tation:

When no pushbutton is pressed for approximately

Actual current value base display

Enter

Enter

Enter

Enter

five seconds, the system returns to the base display.

Set the low limit value

value by pressing the

Set the BUS address

Set the display orien-

by pressing the

pushbutton briefly.

Set the high limit

pushbutton briefly.

pushbutton briefly.

1 = fixed circuit 1 2 = fixed circuit 2

3 = automatic

by pressing the

Enter

Enter

Enter

Enter

The ActivePSM is connected to the CMC-TC Processing Unit II (in short, PUII) using one of the RJ45 connections of the Processing Unit. This socket also functions as the power supply for the module display. The connection between the PUII and the ActivePSM is made using a special adaptor cable and a Cat5 cable (7320.472). The adaptor cable is included in the scope of supply. The connecting cables must not exceed the specified maximum length of 10 m, otherwise Rittal cannot warrant that the product will function correctly.

Insert the Cat5 cable in the provided sockets of the PU and in the adaptor cable of the ActivePSM.

Note!

Prior to the installation and commissioning, read and observe the Installation and Operating Instructions, in particular, the contained safety notes.

These operating instructions are available in two languages as a downloadable PDF file at <u>http://www.rimatrix5.com</u>.

Assembly

Before commencing the installation, ensure the completeness of the scope of supply. Also ensure that the system complies with the admissible conditions of use, in particular, the permitted ambient temperatures and the required IP protection category.

7.12.6 Monitoring Using a Browser EN PSM4 [PSM4-Modul] 1 3 2 4 1 4.0 A Current 2 OK Status 4.0 2 Current 0.0 A L Status off Current 0.0 A Off Status Current 0.0 A Status ок 0.0 0.0 0.0 Clear Refresh No Alarn

Fig. 35 ActivePSM browser display

Key 1

- Current: Display of the actual current value of the consumers (server, etc.) connected to the ActivePSM.
- 2 Status: Indicates whether the specified current limit value is observed. A message will be issued if the current lies outside the limit values.
- 3 Position: Indicates the installation position (0° or 180°) of the associated module.

7.12.7 Configuring the ActivePSM

Navigation			
Main menu – Status – Click 1 Current			
Parameter	Explanation		
1n	Connection number of the sen- sor.		
Туре	Sensor type. Will be detected automatically.		
Sensor Status	Sensor status. Green = OK, red = alarm.		
Message Text	The message text which is also transferred when a warning message is sent. Enter here a designation that uniquely identi- fies your sensor, e.g. "Current Rack01".		
Setpoint High	Current limit which when over- shot causes an alarm message to be issued.		
Setpoint Low	Current limit which when over- shot causes an alarm message to be issued.		

Integration of ActivePSM and PSM Busbars

The ActivePSM is centred over the busbar's plug connector and pressed on under gentle force. The ActivePSM is connected correctly when all four of the ActivePSM's catches are engaged in the busbar. To remove the module from the bus, you must carefully retract and withdraw all four catches at the same time.

Ensure no consumers are connected to the sockets, otherwise they will be disconnected from the power supply when the module is removed from the busbar.

In addition, you must note the direction in which the ActivePSM is connected. The busbar also serves as a redundant power supply, so the ActivePSM can be installed in either direction between Circuit 1 and Circuit 2.

Power supply: The power is supplied to the ActivePSM electronics from the CMC-TC Processing Unit II (PUII). This requires that the Category 5 patch cable is inserted in the RJ 45 socket of the PUII and in the adaptor cable of the ActivePSM. Up to four modules can be connected in series on a PUII channel. Unique addresses must be assigned for each module (1, 2, 3, 4).

Note!

For the series connection of PSM modules to the PUII, only one active PSM module type can be cascaded for each sensor unit input of the PUII.

Example:

Sensor input 1: 3x active PSM (4-way, 7865.200)

Sensor input 2: 4x active PSM (8-way, 7856.201)

Sensor input 3: 2x active PSM (8-way, 7200.001)

Cascaded PSM modules must be numbered consecutively (module 1= address 1, module 2 = address 2, etc.)

If only one module is connected, address 1 must be specified here.

Once the ActivePSM is supplied with power, 0.0 A appears on the display. The display shows the immediate active current drawn by diverse consumers when they are connected to the sockets.

Delay	Time in seconds how long the power socket should remain switched off.
Relay Output	Off = manual disable of the PSM module; On = manual enable of the PSM module.
Accept	Accept the changes.
Reset	Reset all settings to the values saved most recently; any changes are not accepted.

	rated with the ampersand char- acter "&" (e.g. 1&2&3&4).
Accept	Accept the changes.
Reset	Reset all settings to the values saved most recently; any changes are not accepted.

Navigation			
Main menu – Sta	atus – Click 3 Position		
Parameter	Explanation		
1n	Connection number of the sen- sor.		
Туре	Sensor type. Will be detected automatically.		
Sensor Status	Sensor status. Black = Circuit 1, blue = Circuit 2		
Trap Receiver	Specify which of the entered trap receivers is to be sent alarm messages. Enter the trap receivers at 7.3.2 Configuring the Trap Receiver.		
Scheduled Alarm Off	Specify which alarm configura- tion should be enabled or dis- abled. The individual functions can be setup from the "Setup – Timer" menu item.		
Send SMS	You can enter up to four mobile wireless numbers that you en- tered previously at Setup – SMS Unit; each number is separated with the ampersand character "&" (e.g. 1&2&3&4).		
Send E-Mail	You can enter up to four e-mail addresses that you entered previously at Setup – E-Mail (SMTP); each number is sepa- rated with the ampersand char- acter "&" (e.g. 1&2&3&4).		
Accept	Accept the changes.		
Reset	Reset all settings to the values saved most recently; any changes are not accepted.		

Navigation		
Main menu – Status – Click 2 Status		
Parameter	Explanation	
1n	Connection number of the sensor.	
Туре	Sensor type. Will be detected automatically.	
Sensor Status	Sensor status. Green = OK, red = alarm.	
Alarm Relay	Whether (enable) or not (dis- able) an alarm relay should switch in the event of an alarm.	
Alarm Beeper	Whether (enable) or not (dis- able) an audio signal should be issued in the event of an alarm.	
Alarm Reset	Should an alarm be acknowl- edged automatically (Auto) or does it need to be acknowl- edged by the administrator (Manual).	
Trap Receiver	Specify which of the entered trap receivers is to be sent status messages. Enter the trap receivers at 7.3.2 Configuring the Trap Receiver.	
Scheduled Alarm Off	Specify which alarm configura- tion should be enabled or dis- abled. The individual functions can be setup from the "Setup – Timer" menu item.	
Send SMS	You can enter up to four mobile wireless numbers that you en- tered previously at Setup – SMS Unit; each number is separated with the ampersand character "&" (e.g. 1&2&3&4).	
Send E-Mail	You can enter up to four e-mail addresses that you entered previously at Setup – E-Mail (SMTP): each number is sepa-	

7.13 Metered PSM



Note!

The installation and commissioning of the PSM busbars with measurement is described in the operating guide for the Metered PSM.

7.14 Monitoring the LCP and RTT I/O Unit

The LCP/RTT I/O unit is connected to the CMC-TC Processing Unit II (in short PUII) using one of the four RJ45 connections.

Note!

The installation and commissioning of the LCP and RTT-I/O unit is described in the operating instructions for the LCP or RTT I/O unit.



Fig. 36 Establishing the sensor connection

Key

1 Sensor units connections (1-4)

2 Status LEDs for connected sensor units

The network connection of the PUII (item 1) is made using the network cable with RJ45 plug in the existing Ethernet network structure.

The data connection exists when the appropriate Link LED (item 2) illuminates green/orange. Establishing the connection for the RTT I/O unit can take as long as 70 seconds.

7.15 Access Control Using an External Access File

An extended access control is integrated in the Processing Unit II software. The access codes can be edited using a text file sent by FTP to the PUII. This form of access control has the following properties:

a keypad (or card reader) can be used to control up to eight doors on four Access Units.

Up to 200 different codes can be stored (each code can release up to eight doors concurrently).

If several identical codes with different authorisations are entered, only the first entry will be used.

The file must have the name **'access.cmc'** and can be created and edited using any ASCII text editor (e.g. Notepad). A line with the following syntax must be created for each access code:

"1234" ,	"0102" =	user	7.16 Saving and Transferring Configura-
		User identification: This optional maxi- mum 8-digit decimal number (10000- 99999999) can be used to specify	This function can be used to save the configuration for the CMC-TC system and, if necessary, restore it to the system later. The configuration can also be transferred to other CMC-TC systems that have the identical wiring and construction.
	Separa	whether a user identi- fication will be sent with the trap message.	Note! Warning, this function may only be used when the CMC-TC systems are identical with regard to:
	Door releas contains a each of the Units. This door is to b	se: This 4-digit number decimal number 03 for four possible Access number specifies which e released:	 sensor types and the used ports sensor units and the used ports and addresses software versions In addition, no sensors or sensor units may be missing or connected in a differ-
	0 - do 1 - rele 2 - rele 3 - rele This numbe	not release any door ease door 1 ease door 2 ease door 1 and 2 er must always contain	ent sequence. If these conditions are not observed, the PUII system will not accept the configura- tion.
Sepa	four digits, Access Uni must be sp Units that a arator: (e.g. cor	irrespective of how many its are connected; a '0' ecified for any Access are not present. mma)	Save configuration files: Once the commissioning, installation and the set- tings of all text items, limit values, links, network settings, etc., has been completed, this information can be saved on an external system (network PC).
Release co tains the re entered on	ode: This 4-digi lease code en the magnetic de can have th	it decimal number con- tered from the keypad or card or chip card. The	The FTP or SFTP protocol can be used to establish access to the Download directory in the PUII. The three files can be loaded and saved on a network PC there
four digits In contrast range can mal numbe	nust always be to the code inp be entered her r must always	e namber 000 to 9999, e entered. out from the web page, no re. A unique 4-digit deci- be specified.	cmc.cfg System data (cannot be edited) cmc.user User administration data (cannot be edited)
The normal cess file is codes store	access contro copied to the P d in the file nor	I is voided when this ac- rocessing Unit II, i.e. the w have priority. To reacti-	net.cfg Network settings (can be edited) The changes are accepted immediately after trans- ferring the file. The correctness of the transfer can be seen in the event log.
deleted usir sations to b entered. To be performe transfer to t	e lost and new enter the defa dafter the file he Processing	auses all access authori- authorisations must be ult values, a reboot must has been deleted. The Unit II is made with FTP	Note! Warning, during the editing of the net.cfg file, under no circumstances may the for- mat or the file structure be changed. If this is not observed, the system may suffer a complete failure.

Transferring configuration files:

Prerequisite -> The three configuration files have been saved beforehand.

The FTP or SFTP protocol can be used to establish access to the Upload directory in the PUII.

the 'upload' directory.

by the 'admin' user. The file must be transferred to

It is possible to connect up to eight keypads (or card readers) to the system. This requires, however, that

a door (handle and access sensor) is present at the connection to which the keypad (card reader) is

connected. These maximum eight keypads (card readers) all have the same authority. This means,

irrespective where the code is entered, the door(s)

specified in the access file will be released.

Configuration files on the target device to which transfers are made:

cmc.cfg	Installation data (cannot be edited)
cmc.user	User administration data
	(cannot be edited)

Network settings (can be edited)

8 Maintenance and Cleaning

The Rittal CMC-TC Processing Unit is a maintenance-free system. The housing does not need to be opened for the installation or during operation.



net.cfg

Note!

Opening the housing or any accessory components will void any warranty and liability claims.

8.1.1 Cleaning



Warning!

Danger of damage! Do not use any aggressive substances, such as white spirit, acid, etc., for cleaning because such substances can damage the unit.

Use a slightly moistened soft cloth to clean the housing.

9 Storage and Disposal

9.1.1 Storage

If the device is not used for a longer period, we recommend that it is disconnected from the mains power supply and protected from dampness and dust.

Further information concerning the operating conditions is contained in the technical specifications.

9.1.2 Disposal

Because the CMC-TC Processing Unit consists primarily of the housing and PCB, the unit must be disposed of through the electronic waste recycling system when it is no longer required. EN

10 Changes from software version 2.6

A number of changes and new functions have been implemented in various areas of the CMC-TC Processing Unit II from software version 2.6. These amendments are documented in this chapter.

10.1 Language selection for the browser interface

The menu item

Setup > General > Language

(German: Einstellung > Allgemein > Sprache)

permits you to switch between the English and German versions of the browser interface.

This language setting is used not only for the browser interface, but also for log files, e-mail texts, SMS texts and the display output.

10.2 Extended options under "Combinations"

Switching combinations, e.g. for the digital relay output module (see Chapter 7.7.14), were in the past limited to combinations of two sensor values. From software version 2.6, it is possible to define logical combinations of up to four sensors. To this end, the sensors are first configured in two "groups" of two sensors each. These groups can then be combined by way of a further AND or OR operation.



Fig. 37 Extended "Combinations" configuration

Key 1

2

3

- Group 1: Combination of the first two sensors. The sensors and logic operation can be chosen freely using any of the connected sensors.
- Group 2: Combination of sensors 3 and 4. The sensors and logic operation can be chosen freely using any of the connected sensors.
- Combination of the two groups (AND/OR operation). The final result then controls triggering of the action. In this example, the door is unlocked.

10.3 New functions for the alarm and event log

Two new functions have been added to the alarm and event log (see Chapter 7.6.8): **Delete** and **Refresh**.

10.01.2009 / 03:40:50 10.01.2009 / 03:41:57 10.01.2009 / 03:38:57 10.01.2009 / 03:37:57 10.01.2009 / 03:11:58 10.01.2009 / 02:18:57 10.01.2009 / 02:17:57	CMC-TC-IOW[03]03], vor dem Fenster: OK (-10°C) CMC-TC-IOW[03]03], vor dem Fenster: OK (-10°C) CMC-TC-IOW[03]03], vor dem Fenster: OK (-10°C) CMC-TC-IOW[03]03], vor dem Fenster: Zu niedrig (-11°C) CMC-TC-IOW[03]03], vor dem Fenster: OK (-10°C) CMC-TC-IOW[03]03], vor dem Fenster: Zu niedrig (-11°C) Delete Refresh
Fig. 38 Alarm	and event log

Key

2

- Refresh button: Refreshes the log page and
- displays the latest log entries.

10.4 Test functions for traps, e-mail, SMS and pings

The **alarm simulation menu** is called via the menu item **Administration > Admin > Simulation.** It is here possible to test the e-mail, SMS and trap functions, and to send a ping to a specified IP address.

Alarm Simulation M	enu 🕇
Send Test eMail	Simulate 1
Send Test SMS	Simulate 2
Send Test TRAP	Simulate 3
Send Ping to	Simulate 4

Fig. 39 Alarm simulation menu

Key

- 1 Sends a test e-mail to all e-mail addresses entered under Setup > Email
- 2 Sends a test SMS to all telephone numbers entered under Setup > SMS-Unit
- 3 Sends a test trap to all entered and enabled trap receivers (see Chapter 7.3.2)
- 4 Sends a ping to the specified IP address

10.5 Scaling of the 4...20 mA sensor inputs of the input module

In the settings for the analog sensor input module 7320.520, it is now possible to define start and end values for automatic scaling of the output. In other words, you can specify which measurement values are to correspond to an input of 4 mA or 20 mA. During operation, the Processing Unit II then converts the current input value accordingly before outputting the corresponding measurement value.

It is furthermore possible to specify the unit to be displayed with the measurement values. This serves to simplify evaluation and improves display clarity when using this universal sensor option.

10.6 Server shutdown function

The function **Setup > Shutdown** can be used to shut servers down conditionally via the Processing Unit II. The prerequisite is that an RCCMD client must be installed on the target servers.

Note!

The installation file for the RCCMD client can be downloaded from www.rimatrix5.com under Service&Support > Downloads. A 30-day test licence is also available there.





Key

- 1 Tabs for the 4 server groups. Each group controls up to 10 servers.
- 2 Group 1: Combination of the first two sensors. The sensors and logic operation can be chosen freely using any of the connected sensors.
- 3 Group 2: Combination of sensors 3 and 4. The sensors and logic operation can be chosen freely using any of the connected sensors.
- 4 Combination of the two groups (AND/OR operation). The final result then triggers the shutdown of the server group.
- 5 Each line contains settings for one server. Server Name: Freely chosen server name. IP Address: IP address of the server. Port: Port used to communicate with the RCCMD client (default: 6003). Delay: Delay in seconds before the shutdown command is sent to the server when the switching conditions are met (point 4). Enable: If this check box is marked, the server is shut down if the switching conditions are met (point 4). In addition, the connection to this server will be tested when the Test button (point 6) is clicked.
- 6 Test button to test the connections to the servers.

> Note!

The Test button does <u>not</u> send shutdown commands to the servers!

It merely checks whether communication with the specified servers is possible. This test is performed for all the servers on all four tabs for which the Enable check box is marked.

A maximum of four sensor values, configured in two groups as for the general switching combinations (see chapter 10.2), can be used to shut the servers down on the basis of defined conditions.

The tabs 1 to 4 permit the configuration of four server groups. Within each group, up to 10 servers can be sent a shutdown command on the basis of the specified sensor conditions. The conditions must be defined individually for each server group.

10.7 Configuration of automatic door opening

Fig. 41 shows the configuration screen for the Automatic Door Opening Control Unit 7320.790. Observe also the instructions given in the user manual enclosed with the unit.

	Unit Name Serialnr. / Software	Sensorik 00001/V1.3
1 — 2 — 3 —	1 2 3 Type Output Status 3 Message Text Delay 1 Delay Timeout 1 Trap Receiver Send SMS Send eMail	4 Door Control On □ Door Control □ \$ [Range: 0999s] stay ▼ □ 1 □ 2 □ 3 □ 4/Log □ [Format: 1828.384] □ [Format: 1828.384]
4 —	— Switch Output	C Off C On

Fig. 41 Configuration of automatic door opening

Key

- 1 Current status of the door control.
- 2 Time for which the contact remains open upon opening before switching back to the status closed.
- 3 Timeout response of the door control. Stay: Current status is maintained Open: Door control opens Close: Door control closes
- Manual switching of the door control.
 It is necessary to confirm the action by clicking on Accept

10.8 Delayed alarms

To prevent a warning or alarm being issued in case of insignificant short-time fluctuations, it is possible to define a delay time for each sensor.

	Setup S	Sensorunit 2 [IO Unit]
	Unit Name Serialnr. / Software	Смс-тс-ю 10779 / V1.3
	1 2 3	4
	Туре	Humidity Sensor
	Sensor Status	24 % rH [OK]
	Message Text	Feuchtesensor
	Setpoint High	85 % rH [Range: 0100% rH]
	Setpoint Warning	65 % rH [Range: 0100% rH]
	Setpoint Low	0 % rH (Range: 0100% rH)
1 —	— Alarm Delay	0 s [Range: 0999s]
	Alarm Relay	O Disable ⊙ Enable
	Alarm Beeper	O Disable ⊙ Enable
	Alarm Reset	💿 Auto 🔾 Manual
	Trap Receiver	☑1 ☑2 ☑3 ☑4/Log
	Scheduled Alarm Of	ff <u>12234</u>
	Send SMS	1 [Format: 1&2&3&4]
	Send eMail	1 [Format: 1&2&3&4]
		Accept Reset

Fig. 42 Configuration of delayed alarms

Key

1 Alarm Delay: Delay between exceeding of the threshold value and actual issuing of an alarm. The time must be specified in seconds (between 0 and 999 seconds).

The "Alarm Delay" value defines how long a threshold value must be exceeded before the corresponding warning or alarm is issued.

Example of a temperature sensor: If the alarm delay is set to 120 seconds and the threshold for a warning is set to 50°C, an increase in temperature to 55°C will only result in a warning being issued if this excess temperature is measured for at least 120 seconds. If the measurement falls back below 50°C after 60 seconds, for example, no warning will be issued, despite the fact that the temperature was for a time above the defined threshold value.



Note!

It is not possible to enter "Alarm Delay" values for ActivePSM busbars/modules.

10.9 Protection against cross-site scripting (XSS)

As protection against a cross-site scripting attack, the input fields of the browser interface, e.g. the message texts, accept only a certain set of characters.

The permissible characters are:

- A-Z, a-z
- 0-9
- _.,;=+:?/%\$*@-&()
- Space

All other characters are deemed invalid and are automatically rejected.

EN

11 Customer Service

If you have any technical questions or questions concerning our product spectrum, contact the following service address:

Tel.: +49 (0)2772/505-1855 http://www.rimatrix5.de E-mail: info@rittal.de



Note!

To allow us to process your enquiry quickly and correctly, please always specify the article number in the subject line for e-mails.

Further information and the current operating guides and updates of the Rittal CMC-TC are available for download under Security on the Rimatrix5 homepage.

12 Technical Specifications

Designation	СМС-ТС	
Housing		
Housing type	Plastic covering with metal trim	
Height	1 U / 44.5 mm	
Width	136 mm	
Depth	129 mm	
Weight without packaging	approx. 0.6 kg	
Potential equa- lisation	_ 1)	
Earthing	_ 1)	
Protection category	IP 40 to EN 60529	
Interfaces		
Pushbuttons	1 membrane pushbutton, ac- knowledge pushbutton	
Front socket	1 x RJ10 socket (RS 232 serial interface)	
LED display	6 x (active/alarm, link, for each connectable sensor island)	
Acoustic signal	1 x piezo signal transmitter	
I ² C connection	RJ45 socket (P-I ² C), shielded	
Alarm relay		
Output	1 x RJ12 socket, shielded	
Configuration	Potential-free change-over contact	
Rated voltage	24 V DC, internal or 24 V for external power supply	
Current	200 mA	
Operational are	а	
Temperature	+5 to +45 °C +42 to +113 °F	
Humidity	5 – 95 %	
Storage tem- perature	-20 to +60 °C -4 to +140 °F	
Rated voltage	1 x 24 V DC 2.5 A SELV	
Fuse	Miniature fuse T2A, 250 V, UL approval	
Network	1 x RJ-45 socket (Ethernet, 10/100 BaseT), shielded	
Sensor island	4 x RJ45 sockets, shielded, for shielded twisted-pair patch cable, Category 5	

3		

MIB (Management Information Base) The MIB was developed to fetch and change network elements. The MIB II was defined in the RFC 1213. Some manufacturers define their own MIBs that provide information about the special properties of their product. The MIBs are registered for the OID with the IANA (Internet Assigned Numbers Authority). Once an object has been assigned to an OID, the meaning can no longer be changed. There also cannot be any overlapping with other OIDs.

Technical Glossary 1

SMS service number

This is a telephone number that the telephone provider makes available for sending SMS messages.

SNMP (Simple Network Management Protocol)

The SNMP is a simple network management protocol based on TCP/IP. It was developed to monitor network components on a central management station.

Telnet

Telnet is a protocol for guest access to a remote server. The Telnet program provides the required client functions of the protocol.

Trap

Trap is the sending of SNMP messages.

Trap Receiver

The trap receiver is the receiver of SNMP messages.

Web Access

The Web Access is used to define the access possibility via the Internet.

Technical Specifications

Maximum cable length

PU to I/O Unit

PU to the Ac-

PU to the Cli-

cess Unit

mate Unit

PU to the

Protocols

Available

protocols

Unit

Wireless I/O

¹⁾ Not required because safety extra-low voltage 24 V DC

maximum 50 m

- SNMP v1 (incl. MIB II)

- http, https, SSL 3.0

- TCP/IP

- SNMP v3 - TELNET, SSH

- FTP, SFTP

- NTP - DHCP

10 m, after consultation with Rittal

maximum 50 m, UL approval

maximum 50 m, UL approval

maximum 50 m, UL approval

13 Technical Glossary

CMC-TC

CMC-TC (Computer Multi Control – Top Concept) is a Rittal product used to monitor network enclosure components.

GSM card

A GSM card is a telephone card for a mobile telephone.

Internet browser

An Internet browser can be used to display html pages (and pages that conform to a similar standard). In the case of CMC-TC PU, they can be configured using a user interface displayed with an Internet browser.

Link

A link causes a jump to another Internet page or establishes a connection between two Internet pages.

MAC address

The MAC address is a unique combination of alphabetic characters and digits assigned to a network interface that may be assigned just once throughout the world. One of its uses is to identify a network interface in a network.

14 Declaration of Conformity

EN 14 Declaration of Conformity

Reg. Nr.: 5 232 302 - 1	
Nir Ne	RITTAL
Rittal	
SmbH & Co. KG	
Postfach 16 62 35726 Herborn	
Germany	
erklären, dass das Produkt	
leciare that the product	•
CMC-TC - Schranküberwachung	
Reck-Monitorina and Control	
CMC-TC	/
DK 7320.100 CMC-TC Prozessor Unit (PU)	
DK 7320.111 BasicCMC	1 (IQUI)
DK 7320.210 CMC-TC Sensoreinheit I/O Uni DK 7320.220 CMC-TC Sensoreinheit Access	(IOU)
DK 7320.230 CMC-TC Sensoreinheit Climate	e Unit (CU)
mit der/den folgenden Norm(en) oder Norma	tiven Dokument(en) übereinstimmt.
EN 60950-1 Ausgabe 2003/03	save occument(s)
EN 55022 Ausgabe 2003/09	
EN 61000-3-2 Ausgabe 2006/10 EN 61000-3-3 Ausgabe 2006/06	
EN 61000-6-2 Ausgabe 2006/03	
EN 61000-6-3 Ausgabe 2005/06	
Gemäß den Bestimmungen der Richtlinie(n)	
onowing the provisions of Directive(s)	
Niederspannungsrichtlinie Nr.: 73/23/EWG	und Änderungen
EMV – Richtlinie Nr.: 89/336/EWG	und Änderungen and updates
	0
Herborn, 28 Dezember 04	full.
Herborn, 28 Dezember 04	

NWGQ7 October 23, 2003 Information Technology Equipment Including Electrical Business Equipment Certified for Canada

RITTAL GMBH & CO KG AUF DEM STUETZELBERG, 35745 HERBORN GERMANY E215843

LOOK FOR LISTING MARK ON PRODUCT

E215843

NWGQ October 23, 2003 Information Technology Equipment Including Electrical Business Equipment

RITTAL GMBH & CO KG AUF DEM STUETZELBERG, 35745 HERBORN GERMANY

Computer multi control units - Top concept.

Computer multi control units - Top concept, Model(s) CMC - TC AU, CMC - TC CU, CMC - TC IO, CMC - TC PU. LOOK FOR LISTING MARK ON PRODUCT EN