

Performing the firmware update for the CMC-TC master device

DK 7320.000

The update to version 1.40 can only be performed if the master unit at least has version 1.21 installed. If you have a device with an older version please contact the Rittal support team to get an update file that is suitable for older devices.

- **Webpage: Tab – Admin**
- **Firmware update**

For a firmware update of the CMC-TC Master unit the following steps are necessary.

1st step: Activate TFTP-Server of the Master unit

TFTP-Server state (checked if already enabled)

Change TFTP-Server settings

2nd step: Upload the 'update.tar.gz'-file to the master unit via TFTP

3rd step: Now the update file can be set up. After that the master will automatically be rebooted.

Set up update and reboot

First step:

Activating TFTP server on the master device:
Set check mark and confirm with Change TFTP-Server settings.

Second step:

Open the **input prompt** in Windows. Load the update file by TFTP on the master.

Command:

ftftp -i 192.168.30.100 put update.tar.gz

Third step:

Install the update and restart the master using the **Set up update and reboot** button.